

PSM3750 - NumetriQ

USER MANUAL



" Do not be hasty when making measurements."

NumetriQ is a precision instrument that provides you with the tools to make a wide variety of measurements accurately, reliably, and efficiently - but good metrology practice must be observed. Take time to read this manual and familiarise yourself with the features of the instrument in order to use it most effectively.



DANGER OF ELECTRIC SHOCK

Only qualified personnel should install this equipment, after reading and understanding this user manual. If in doubt, consult your supplier.



RISQUE D'ELECTROCUTION

L'installation de cet équipement ne doit être confiée qu'à un personnel qualifié ayant lu et compris le présent manuel d'utilisation. Dans le doute, s'adresser au fournisseur.



GEFAHR VON ELEKTRISCHEM SCHOCK

Nur entsprechend ausgebildetes Personal ist berechtigt, diese Ausrüstung nach dem Lesen und Verständnis dieses Anwendungshandbuches zu installieren. Falls Sie Zweifel haben sollten, wenden Sie sich bitte an Ihren Lieferanten.



RISCHIO DI SCARICHE ELETTRICHE

Solo personale qualificato può installare questo strumento, dopo la lettura e la comprensione di questo manuale. Se esistono dubbiconsultate il vostro rivenditore.



PELIGRO DE DESCARGA ELÉCTRICA

Solo personal cualificado debe instalar este instrumento, después de la lectura y comprensión de este manual de usuario. En caso de duda, consultar con su suministrador.

IMPORTANT SAFETY INSTRUCTIONS

This equipment is designed to comply with BSEN 61010-1 (Safety requirements for electrical equipment for measurement, control, and laboratory use) – observe the following precautions:

- Ensure that the supply voltage agrees with the rating of the instrument printed on the back panel **before** connecting the mains cord to the supply.
- This appliance *must* be earthed. Ensure that the instrument is powered from a properly grounded supply.
- The inputs and outputs must not be connected to common mode signals greater than 500V peak.
- The inputs must not be connected to signals greater than 500V peak.
- Keep the ventilation holes on the underneath and sides free from obstruction.
- Do not operate or store under conditions where condensation may occur or where conducting debris may enter the case.
- There are no user serviceable parts inside the instrument – do not attempt to open the instrument, refer service to the manufacturer or his appointed agent.

Note: Newtons4th Ltd. shall not be liable for any consequential damages, losses, costs or expenses arising from the use or misuse of this product however caused.

DECLARATION OF CONFORMITY

Manufacturer: Newtons4th Ltd. Address: 30 Loughborough Rd. Mountsorrel Loughborough Leics. LE12 7AT

We declare that the product:

Description: Phase Sensitive Multimeter Product name: NumetriQ Model: PSM3750

conforms to the requirements of Council Directives:

89/336/EEC relating to electromagnetic compatibility: EN 61326:1997 Class A

73/23/EEC relating to safety of laboratory equipment: EN 61010-1

July 2013

Eur Ing Allan Winsor BSc CEng MIEE (Director Newtons4th Ltd.)

WARRANTY

This product is guaranteed to be free from defects in materials and workmanship for a period of 12 months from the date of purchase.

In the unlikely event of any problem within this guarantee period, first contact Newtons4th Ltd. or your local representative, to give a description of the problem. Please have as much relevant information to hand as possible – particularly the serial number and release numbers (press SYSTEM then LEFT).

If the problem cannot be resolved directly then you will be given an RMA number and asked to return the unit. The unit will be repaired or replaced at the sole discretion of Newtons4th Ltd.

This guarantee is limited to the cost of the NumetriQ itself and does not extend to any consequential damage or losses whatsoever including, but not limited to, any loss of earnings arising from a failure of the product or software.

In the event of any problem with the instrument outside of the guarantee period, Newtons4th Ltd. offers a full repair and re-calibration service – contact your local representative. It is recommended that NumetriQ be recalibrated annually.

ABOUT THIS MANUAL

PSM3750 has of number of separate measurement functions that share common resources such as the keyboard and display.

Accordingly, this manual first describes the general features and specification of the instrument as a whole; and then describes the individual functions in detail.

Each function is described in turn, in its own chapter, with details of the principles on which it is based, how to use it, the options available, display options, specifications etc.

Detailed descriptions of the RS232 command set is given in the separate manual "PSM3750 communications manual".

Revision 1.01

This manual is copyright © 2013 Newtons4th Ltd. and all rights are reserved. No part may be copied or reproduced in any form without prior written consent.

3 July 2013

PSM3750 user manual

<u>CONTENTS</u>

1	Intro	oduction – general principles of operation	1-1	
	1.1 1.2	Generator output Voltage inputs	1-4 1-5	
2	Gett	ing started	2-1	
	2.1 2.2 2.3	Unpacking Keyboard and controls Basic operation	2-1 2-3 2-4	
3	Usin	g the menus	3-1	
	3.1 3.2 3.3	Selection from a list Numeric data entry Text entry	3-3 3-4 3-5	
4	Spec	cial functions	4-1	
	4.1 4.2 4.3 4.4 4.5 4.6 4.7	Display zoom. Program store and recall. Zero compensation. Alarm function . Analogue output . Data hold . Sweep results store and recall .	4-1 4-2 4-3 4-4 4-6 4-7 4-8	
5	Usin	g remote control	5-1	
	5.1 5.2 5.3	Standard event status register Serial Poll status byte RS232 connections	5-3 5-4 5-5	
6	Syst	em options	6-1	
	6.1	User data	6-3	
7	Meas	surement options	7-1	
	7.1 7.2 7.3 7.4	ACQU - Acquisition options Datalog SWEEP - Frequency sweep options TRIM - Trim function	7-1 7-4 7-6 7-8	
8	8 Output control 8-			
	8.1	Generator specifications	8-3	

9	Inpu	It channels	9-1
9	.1	Trimming x10 oscilloscope probes	
10	True	RMS Voltmeter	10-1
1	0.1	RMS voltmeter specification	10-5
11	Freq	uency response analyser	11-1
1 1	1.1 1.2	Frequency response analyser specification Feedback Loop Analysis quick user guide	11-4 11-5
12	Phas	se angle voltmeter (vector voltmeter)	12-1
1	2.1	Phase angle voltmeter specification	12-4
13	Pow	er meter	13-1
1	3.1	Power meter specification	13-5
14	LCR	meter	14-1
1	4.1	LCR meter specification	14-7
15	Harr	nonic analyser	15-1
1	5.1	Harmonic analyser specification	15-4
16	Tran	sformer analyser	16-1
1 1 1 1 1 1 1 1	6.1 6.2 6.3 6.4 6.5 6.6 6.7 6.8 6.9 6.10	Turns ratio Inductance & leakage inductance AC resistance and Q factor DC resistance Interwinding capacitance Magnetising current Return loss Insertion loss Harmonics and distortion	16-3 16-4 16-5 16-5 16-6 16-7 16-8 16-9 16-11
I	0. IU		

PSM3750 user manual

APPENDICES

- Appendix A Accessories
- Appendix B Serial command summary
- Appendix C Available character set
- Appendix D Configurable parameters
- Appendix E Contact details

1 <u>Introduction – general principles of operation</u>

NumetriQ is a self-contained test instrument, with one output and two or three inputs, which incorporates a suite of test functions.

NumetriQ has a wide bandwidth, isolated, generator output that can be used as signal generator for sine, square, triangle, or sawtooth waveforms, or true white noise. A dc offset may be added to the signal generator output. The output is fully isolated from earth to 600Vpk cat II.

NumetriQ has two or three isolated, high bandwidth, voltage inputs, which use direct digital analysis at low frequencies and a heterodyning technique to give high accuracy at high frequencies. The inputs are fully isolated from each other and from earth to 600Vpk cat II.

NumetriQ has two processors:

- a DSP (digital signal processor) for data analysis
- a CPU (central processing unit) for control and display

At the heart of the system is an FPGA (field programmable gate array) that interfaces the various elements, see diagram below:



This general purpose structure provides a versatile hardware platform that can be configured by firmware to provide a variety of test functions, including:

Signal generator Two channel true rms voltmeter Phase angle voltmeter (vector voltmeter) Frequency response analyser (gain/phase analyser) Harmonic analyser

With additional external interfaces, such as current shunts, other functions are possible:

True rms current meter LCR meter Power meter

NumetriQ is configured to perform the required test function by simple user menus, or can be controlled remotely via a serial interface (RS232), or optionally LAN interface or GPIB interface. The programmable nature of the instrument means that new functions can be added as they become available, or existing functions can be enhanced, by simple firmware download.

1.1 <u>Generator output</u>

The output sinewave is generated by direct digital synthesis (DDS). Amplitude is set in 2 stages - a fine control and a coarse control to give good resolution over the whole range. The output, has a variable offset added, is filtered and is buffered by a high speed, high current buffer. There is also an earth referenced TTL Sync output for oscilloscope synchronization etc, constantly running at the selected generator frequency.

The DDS is clocked at 210 MHz. The DAC resolution is 14 bit. The fine amplitude control is 10 bit (0.1% fsd). The coarse amplitude control is 4 bit. The maximum output level is \pm 10V peak. The maximum output current is \pm 200mA peak. The OV of the output is isolated from earth. The output impedance is 50 Ω . The output frequency range is 10uHz to 50MHz. The Sync output is TTL level at generator frequency.



1.2 <u>Voltage inputs</u>

Each input consists of a pair of ac, or ac+dc, coupled high impedance buffers, one for the high voltages and one for lower voltages. The BNC safety connector and 4mm safety connectors are in parallel – either connector may be used.

After the selectable heterodyning and filtering, there is a series of gain stages leading to an A/D converter. The data from the A/D is transmitted across an isolation barrier to the DSP. Selection of the input gain, the heterodyning and the sampling of the A/D converter are under the control of the DSP. There is an autozero switch at the front end for dc accuracy.

The maximum input is ±500V peak. The full scale of the lowest range is ±3mV peak. The input frequency range is dc to 50 MHz. The A/D converter resolution is 14 bit. The A/D sample rate is variable to 1M samples/s.



high Z input buffers

gain

2 Getting started

The NumetriQ is supplied ready to use – it comes complete with an appropriate power lead and a set of test leads. It is supplied calibrated and does not require anything to be done by the user before it can be put into service.

2.1 <u>Unpacking</u>

Inside the carton there should be the following items:

one NumetriQ unit one appropriate mains lead two or three voltage probes one BNC output lead with clips one null modem cable to connect to a computer one USB to connect to a computer this manual one communications manual

Having verified that the entire above list of contents is present, it would be wise to verify that your NumetriQ operates correctly and has not been damaged in transit.

First verify that the voltage rating on the rear of the NumetriQ is appropriate for the supply, then connect the mains cord to the inlet on the rear panel of the NumetriQ and the supply outlet.

Switch on the NumetriQ. The display should illuminate with the model name and the firmware version for a few seconds while it performs some initial tests. It should then default to the FRA display. Note that the switch on message can be personalised – see the User Data section under System Options. The generator is off by default so the display may read some random values due to noise pick up. Connect the output lead to the output BNC of the NumetriQ and input probes to the BNC on each of the input channels. Connect the output to all the inputs by connecting the black clip on the output lead to the OV clip on each of the input probes, and the red clip of the output lead to the input probes. Note that this is easiest to do by connecting across a resistor (any value above 1k).

Press the OUT key to invoke the output menu, then press the UP key to select the output on/off control then the RIGHT key to turn on the output by selecting "on".

Exit the menu by pressing the ENTER button or the HOME button *twice*.

The display should now indicate a magnitude value of about 1.4V on all channels, each of which should indicate the 3V range; check that the gain reads 0.000dB ± 0.010 dB, and that the phase reads 0.000° ± 0.010 °.

In the event of any problem with this procedure, please contact customer services at Newtons4th Ltd. or your local authorised representative: contact addresses and telephone numbers are given in the appendix at the back of this manual.

2.2 <u>Keyboard and controls</u>

The keyboard is divided into 5 blocks of keys: display control (5 keys top left) function keys (6 keys top right) setup keys (12 keys lower left) menu control keys (7 centre keys) action keys (4 keys lower right)

In normal operation, the cursor keys give one-touch adjustment of various parameters, such as generator amplitude and frequency, without having to access the menu system.

The setup keys provide access to the menus and are used for numeric data entry.

The function keys (FRA, PAV, LCR, RMS, POWER and SCOPE) are also used for entering the multipliers (G, M, k, m, u, n) for date entry and letters for text entry.

2.3 <u>Basic operation</u>

The required function can be selected by pressing the function key, FRA, PAV, LCR, RMS, POWER, or SCOPE. Pressing the same function key again brings up the menu options specific to that function. For example, press PAV to select phase angle voltmeter mode; press PAV again to gain access to the PAV specific menu options.

Alternatively, press MODE to bring up the function specific menus.

There are a number of menus available to configure the instrument. All of these menus are directly accessible with one press of the appropriate menu key. The cursor keys allow navigation around the menus and also control the generator when not accessing a menu.

For example, to turn on the output, press OUT to bring up the generator control menu, press UP to select the output on/off option, press RIGHT to select the output from the available options. Press ENTER, or HOME twice, to exit the menu. Press FRA to select frequency response analyser mode and the instrument will now display the gain and phase of the transfer function of the circuit under test at the spot frequency specified by the output control menu.

Press LEFT or RIGHT to adjust the frequency, Press UP or DOWN to adjust the amplitude (use the OUT menu to change the size of the steps).

Press START and NumetriQ will start a frequency sweep over the specified range (set in the SWEEP menu); press TABLE to see the table of results, GRAPH to see a graph of the results and REAL TIME to return to the real time data.

3 Using the menus

NumetriQ is a very versatile instrument with many configurable parameters. These parameters are accessed from the front panel via a number of menus.

Each of the main menus may be accessed directly from a specific key.

ACQU	data acquisition parameters such as speed and filtering
SWEEP	frequency sweep control
TRIM	generator trim control (amplitude
	compression)
COMMS	communications options (RS232 etc)
ALARM	control of audible alarm and analogue output
OUT	signal generator control
CH1	channel 1 input control
CH2	channel 2 input control (and channel 3)
SYS	general system options such as phase
	convention, keyboard beep etc.
MODE	function control
PROG	recall/store/ delete of non-volatile programs

Each menu starts with the currently set parameters visible but no cursor. In this condition, pressing the menu key again or the HOME key aborts the menu operation and reverts back to normal operation.

To select any parameter, press the UP or DOWN key and a flashing box will move around the menu selecting each parameter. In this condition the keys take on their secondary function such as numbers 0-9, multipliers n-G etc.

Pressing the HOME key first time reverts to the opening state where the parameters are displayed but the cursor is

hidden. Pressing the HOME key at this point exits the menu sequence and reverts back to normal operation.

To abort the menu sequence, press the HOME key twice.

There are three types of data entry: selection from a list numeric text

3.1 <u>Selection from a list</u>

This data type is used where there are only specific options available such as the output may be 'on' or 'off', the graph drawing algorithm may use 'dots' or 'lines'.

When the flashing cursor is highlighting the parameter, the RIGHT key steps forward through the list, and the LEFT key steps backwards through the list. The number keys 0-9 step directly to that point in the list, which provides a quick way to jump through long lists. There is no need to press the ENTER key with this data type

For example, if the speed selection list comprises the options:

very slow	(item 0)
slow	(item 1)
medium	(item 2)
fast	(item 3)
window	(item 4)

and the presently selected option is "medium", there are 3 ways to select "window":

press RIGHT twice press LEFT three times press number 4

3.2 <u>Numeric data entry</u>

Parameters such as frequency and offset are entered as real numbers; frequency is an example of an unsigned parameter, offset is an example of a signed parameter.

Real numbers are entered using the number keys, multiplier keys, decimal point key, or +/- key (if signed value is permitted). When the character string has been entered, pressing the ENTER key sets the parameter to the new value. Until the ENTER key is pressed, pressing the HOME key aborts the data entry and restores the original number.

If a data value is entered that is beyond the valid limits for that parameter then a warning is issued and the parameter set as close to the requested value as possible. For example, the maximum amplitude of the NumetriQ generator is 10V peak; if a value of 15V is entered, a warning will be given and the amplitude set to the maximum of 10V.

When the parameter is first selected there is no character cursor visible – in this condition, a new number may be entered directly and will overwrite the existing number.

To edit a data value rather than overwrite it, press the RIGHT key and a cursor will appear. New characters are inserted at the cursor position as the keys are pressed, or the character before the cursor position can be deleted with the DELETE key.

Data values are always shown in engineering notation to at least 5 digits (1.0000-999.99 and a multiplier).

3.3 <u>Text entry</u>

There are occasions where it is useful to enter a text string; for example, a non-volatile program may have some text as a title.

Text is entered by selecting one of 6 starting characters using the main function keys on the top right hand side of the keyboard (FRA etc), then stepping forwards or backwards through the alphabet with the UP and DOWN keys.

The starting letters are A (FRA), E (PAV), I (LCR), O (RMS), U (POWER), or space (SCOPE).

Numbers can also be inserted using the number keys.

The UP and DOWN keys step forward and backward using the ASCII character definitions – other printable characters such as # or ! can be obtained by stepping on from the space. The available character set is given in the Appendix.

When entering alphabetic characters, the ZOOM+ and ZOOM- keys select upper and lower case respectively for the character preceding the cursor and the next characters to be entered.

The editing keys, RIGHT, LEFT, DELETE and ENTER operate in the same way as for numeric entry.

4 Special functions

4.1 <u>Display zoom</u>

NumetriQ normally displays many results on the screen in a combination of small font size (no zoom) and up to 4 values in a larger font size (first zoom level). There is also an even larger font for up to 4 selected values (second zoom level).

To set the data values for the larger font size, first return to no zoom by pressing ZOOM-, up to three times if necessary. Press ZOOM+ key to view the presently selected data, and press DELETE to clear the selection.

A flashing box surrounds the first available result. The flashing box is moved around the available results using the cursor keys, UP, DOWN, LEFT and RIGHT. Pressing the ENTER key selects the result for zoom and the box ceases to flash. Further results (up to four in total) can then be selected using the cursor keys in the same way – a solid box remains around the already selected item, and a new flashing box appears.

Having selected the desired results, pressing the ZOOM+ key invokes the first zoom level, pressing it again selects the higher level. Pressing ZOOM-, steps back down one level each time.

Note that any of the parameters selected for the zoom function can be used as the input for the alarm monitoring and analogue output.

4.2 <u>Program store and recall</u>

There are 999 non-volatile program locations where the settings for the entire instrument can be saved for recall at a later date. Each of the 999 locations has an associated name of up to 20 characters that can be entered by the user to aid identification.

Program number 1 (if not empty) is loaded when the instrument is powered on, so that NumetriQ can be set to a user defined state whenever it is switched on. This is particularly useful to set system options such as phase convention etc. If no settings have been stored in program 1 then the factory default settings are loaded (program number 0).

Program numbers 1-6 may be recalled with a single press of the function keys if the direct load option is selected in the system menu (see system options).

The instrument can be restored to the factory default settings at any time by recalling program number 0.

The program menu is accessed using the PROG key. The program location can be selected either by stepping through the program locations in turn to see the name, or by entering the program number directly.

When storing a configuration in a program, there will be a slight pause (of about 1 second) if the program has previously been written or deleted. The process will be very quick if the location has not been used.

When supervisor mode is disabled (see system options), programs can only be recalled, not stored nor deleted, to avoid accidental modification.

4.3 Zero compensation

There are 3 levels of zero compensation:

Trim out the dc offset in the input amplifier chain. Measure any remaining offset and compensate. Measure parasitic external values and compensate.

The trim of the dc offset in the input amplifier chain can be manually invoked at any time with the ZERO key, or over the RS232 with the REZERO command.

The measurement of the remaining offset also happens when the offset is trimmed but is also repeated at regular intervals when using a measurement function that requires dc accuracy (such as the rms voltmeter). This is to compensate for any thermal drift in the amplifier chain. This repeated autozero function can be disabled via the SYSTEM OPTIONS menu.

The compensation for parasitic external values (for example to compensate for the capacitance of the test leads when measuring capacitance) is invoked manually by the ZERO key. Refer to each function section for the function specific operations.

Any compensation values are stored along with the instrument configuration when a program is stored.

To restore operation without function specific compensation press ZERO then select the clear option.

4.4 <u>Alarm function</u>

NumetriQ has two independent alarms that can be read remotely or can generate an audible sound each of the alarms can be triggered by comparison to one or two thresholds:

Sound the alarm if the value exceeds a threshold Sound the alarm if the value is below a threshold Sound the alarm if the value is outside a window Sound the alarm if the value is inside a window

Additionally, one of the alarms can be used to generate a sound which varies linearly between thresholds

The value to which each alarm is applied can be any of the measurements selected for zoom. The alarm status is also available as a logic output on the parallel port.

To program an alarm, first select the functions for the zoom; up to four measurements can be selected for the display, the alarm is applied to any of them; then press ALARM to invoke the alarm menu:

Select which of the zoom functions is to be used Select the type of alarm Set the upper limit (if appropriate) Set the lower limit (if appropriate) Select whether the alarm is to be latched Select whether the alarm sounder is enabled

If the alarm latch is selected then the alarm will continue to sound even if the value returns to within the normal boundaries. To clear the alarm, press HOME.

The linear alarm option allows tests to be carried out even if it is not possible to see the display. Pressing ZERO in the alarm menu sets the upper and lower threshold to 4/3 and 1/3 of the measured value respectively. The repetition rate of the sounder then varies linearly as the value changes between these thresholds.

4.5 <u>Analogue output</u>

The analogue output is a 0 to 4V dc level that represents the selected measurement.

To program the analogue output, first select the functions for the zoom; up to four measurements can be selected for the display, the alarm is applied to any one of them; then press ALARM to invoke the alarm and analogue output menu:

Select which of the zoom functions is to be used Set the value for zero volts output Set the analog scaling factor

The analog output level is computed as:

output voltage = 4 * scale * (measurement - zero)

The output is updated whenever new data is available. For maximum update speed, select "fast analogue output" mode in the ACQU menu and enter a window value for 10ms or higher. When START is pressed, the instrument enters a special mode where all non-essential functions are suppressed (including the display). Press STOP to return to the normal display.

4.6 <u>Data hold</u>

When in real time display mode, the data on the display can be held at any time by pressing the REAL TIME key. When HOLD is activated a warning message is briefly displayed and the word HOLD appears in the top right hand corner of the display instead of the time.

Press the REAL TIME key again or the HOME key or START key to release HOLD; in this case, HOME and START do not have their normal functions.

When HOLD has been activated, the DSP continues to sample, compute and filter the results but the data is ignored by the CPU. When HOLD is released the display is updated with the next available value from the DSP.

4.7 <u>Results store and recall</u>

There are 999 non-volatile storage locations that can store either real-time results or frequency sweeps. Each location can store the sweep results for up to 50 points.

When storing a result, a text string may be entered to help identify the data.

Each stored result also saves the instrument configuration along with the data (same as program store/recall), so that the instrument is restored to the same settings when the result is recalled.

The results data may be restored manually or via communications for download to a PC. To manually access the results data store, press PROG and select memory type "results".

5 <u>Using remote control</u>

NumetriQ is fitted with an RS232 and USB serial communications port as standard, and may have an IEEE488 (GPIB) interface or LAN interface fitted as an option. All the interfaces use the same ASCII protocol with the exception of the end of line terminators:

	Rx expects	Tx sends
RS232	carriage return	carriage return
USB	(line feed ignored)	and line feed
LAN	carriage return	carriage return
	(line feed ignored)	and line feed
IEEE488	carriage return or	carriage return
	line feed or EOI	with EOI

All the functions of the NumetriQ can be programmed via either interface, and results read back.

The commands are not case sensitive and white space characters are ignored (e.g. tabs and spaces). Replies from NumetriQ are always upper case, delimited by commas, without spaces.

Only the first six characters of any command are important – any further characters will be ignored. For example, the command to set the generator frequency is FREQUE but the full word FREQUENCY may be sent as the redundant NCY at the end will be ignored.

Fields within a command are delimited by comma, multiple commands can be sent on one line delimited with a semicolon eg.

AMPLIT, 1.5; OUTPUT, ON

Mandatory commands specified in the IEEE488.2 protocol have been implemented, (e.g. *IDN? *RST) and all

commands that expect a reply are terminated with a question mark.

NumetriQ maintains an error status byte consistent with the requirements of the IEEE488.2 protocol (called the standard event status register) that can be read by the mandatory command *ESR? (See section 5.1).

NumetriQ also maintains a status byte consistent with the requirements of the IEEE488.2 protocol, that can be read either with the IEEE488 serial poll function or by the mandatory command *STB? Over RS232 or IEEE or LAN (see section 5.2).

The IEEE address defaults to 23 and can be changed via the COMMS menu.

The keyboard is disabled when the instrument is set to "remote" using the IEEE. Press HOME to return to "local".

RS232 data format is: start bit, 8 data bits (no parity), 1 stop bit. Flow control is RTS/CTS (see section 5.2), baud rate is selectable via the COMMS menu. When connecting to a PC use the supplied null modem cable.

A summary of the available commands is given in the Appendix. Details of each command are given in the communication command manual.

Commands are executed in sequence except for two special characters that are immediately obeyed:

Control T (20) – reset interface (device clear) Control U (21) – warm restart

To maintain compatibility with some communication systems, there is an optional "protocol 2" which requires a space between the command and any arguments.

5.1 <u>Standard event status register</u>

PON	CME	EXE	DDE	QYE	OPC

bit 0	OPC	(operation complete)
		cleared by most commands
		set when data available or sweep complete
bit 2	QYE	(unterminated query error)
		set if no message ready when data read
bit 3	DDE	(device dependent error)
		set when the instrument has an error
bit 4	EXE	(execution error)
		set when the command cannot be executed
bit 5	CME	(command interpretation error)
		set when a command has not been recognised
bit 7	PON	(power on event)
		set when power first applied or unit has reset

The bits in the standard event status register except for OPC are set by the relevant event and cleared by specific command (*ESR? *CLS, *RST). OPC is also cleared by most commands that change any part of the configuration of the instrument (such as MODE or START).

5.2 <u>Serial Poll status byte</u>

ESB	MAV	FDV	SDV	RDV

bit 0	RDV	(result data available) set when results are available to be read as enabled by DAVER
bit 1	SDV	(sweep data available) set when sweep results are available to be read as enabled by DAVER
bit 2	FDV	(fast data available (streaming)) set when data streaming results are available to be read as enabled by DAVER
bit 4	MAV	(message available) set when a message reply is waiting to be read
bit 5	ESB	(standard event summary bit) set if any bit in the standard event status register is set as well as the corresponding bit in the standard event status enable register (set by *ESE).
5.3 RS232 connections

The RS232 port on NumetriQ uses the same pinout as a standard 9 pin serial port on a PC or laptop (9-pin male 'D' type).

Pin	Function	Direction
1 2	DCD RX data	in (+ weak pull up) in
3	TX data	out
4	DTR	out
5	GND	
6	DSR	not used
7	RTS	out
8	CTS	in
9	RI	not used

NumetriQ will only transmit when CTS (pin 8) is asserted, and can only receive if DCD (pin 1) is asserted. NumetriQ constantly asserts (+12V) DTR (pin 4) so this pin can be connected to any unwanted modem control inputs to force operation without handshaking. NumetriQ has a weak pull up on pin 1 as many null modem cables leave it open circuit. In electrically noisy environments, this pin should be driven or connected to pin 4.

To connect NumetriQ to a PC, use a 9 pin female to 9 pin female null modem cable:

1 & 6	-	4
2	-	3
3	-	2
4	-	1 & 6
5	-	5
7	-	8
8	-	7

6 System options

Press SYSTEM to access the system options.

The time and date are maintained by a battery backed real time clock. Time is expressed in 24 hour format.

The display is normally in colour but it can be set to black on white or white on black.

There is a choice of screen brightness – "high" suits most typical environments but "low" may cause less eye strain in low light conditions.

Measurements of phase can be expressed in one of three conventional formats:

-180° to +180° (commonly used in circuit analysis)

 0° to -360° (commonly used in power applications) 0° to +360°

The measurement is exactly the same it is only the way that it is expressed that changes.

Blanking can be applied to a number of measurements so that zero is shown when the measurement is below a certain level. This blanking can be disabled if desired.

Each key press is normally accompanied by an audible 'beep' as well as the tactile 'click'. The 'beep' can be disabled for quiet environments if the feel of the key is sufficient feedback

Regular autozero measurements can be suppressed.

The 6 main function keys, FRA, PAV, LCR, RMS, POWER, HARM, can be used to load stored configurations as a "one-touch" way of configuring the instrument for specific applications. This is particularly useful in a production

environment where an operator has a small number of specific tests to perform.

Most data is displayed to 5 digits but for extra resolution 6 digits can be displayed when in ZOOM level 2 or 3.

When using external shunts or attenuators, the range can be shown either as the normal peak voltage or scaled by the shunt or attenuator factor.

Levels are usually expressed in volts but can be set and displayed in dBm, which is a logarithmic scale referred to 1 mW in 600Ω , often used when testing communications components.

To save these system settings as default, store the setup in program 1 so that they are reloaded on power on.

Pressing RIGHT from the SYSTEM OPTIONS menu selects the USER DATA screen (see next section).

Pressing LEFT from first SYSTEM OPTIONS menu displays the serial number, release versions, and calibration date.

6.1 <u>User data</u>

NumetriQ can be personalised by entering up to 3 lines of user data as text (see section on text entry).

User data is displayed every time that the instrument is switched on to identify the instrument. The entered text may also be read over the communications to identify the instrument (see USER?).

Typical arrangement of the user data might be:

- line 1 company name
- line 2 department or individual name
- line 3 unique identifying number (eg. asset number)

Any user data may be entered as required, as the lines are treated purely as text and are not interpreted by NumetriQ at all.

For use in a production environment, NumetriQ supports two modes of operation, supervisor and user. When supervisor mode is disabled, the stored programs can only be recalled, not changed. In user mode NumetriQ will also not accept any commands which could change the calibration data.

After changing the user data or supervisor status, execute 'store' to save the data in non-volatile memory.

7 <u>Measurement options</u>

7.1 <u>ACQU - Acquisition options</u>

NumetriQ comes in 2 channel or 3 channel version. The 3 channel version can be set to display just 2 channels if the third channel is not in use.

In normal acquisition mode the window over which the measurements are computed is adjusted to give an integral number of cycles of the input waveform. The results from each window are passed through a digital filter equivalent to a first order RC low pass filter.

There are six pre-set speed options – very fast, fast, medium, slow, very slow and window – that adjust the nominal size of the window, and therefore the update rate and the time constant of the filter. Greater stability is obtained at the slower speed at the expense of a slower update rate.

Note that the measurements have to be made over an integral number of cycles of the waveform so the window is extended to cover one or more complete cycles even if this is a longer period than the nominal update rate. The minimum number of cycles to be measured in each window can be set from 1 to 100.

There are two time constants for the filter, normal or slow, or the filter can be deselected. The filter applies an auto reset function to give a fast dynamic response to a change of measurement – this function can be deselected and the filter forced to operate with a fixed time constant for use with noisy signals. The nominal values are:

speed	update rate	normal time constant	slow time constant
very fast	1/50s	0.1s	0.4s
fast	1/12s	0.4s	1.5s
medium	1/3s	1.5s	6s
slow	2.5s	12s	48s
very slow	10s	48s	192s

There is also an option to set a specific size of the window to a value other than the preset options. In order to synchronise to an integral number of cycles, the window size is either reduced by up to 25% or increased as necessary.

The filter dynamics are usually set to "auto reset" where the filtering is reset in response to a significant change in data. This speeds up the response of the instrument to changing conditions. This function can be disabled so that the filtering has a fixed time constant, which would have an exponential response to a step change. The filter can also be reset by pressing TRIGGER.

When the generator is not used and so the measurement is synchronised to the input frequency measured on CH1, there is a low frequency option that extends the frequency measurement down to 20mHz. This low frequency option also applies a digital filter, which can be useful when measuring in a low frequency, noisy environment.

In the case where there is very little signal on CH1, the reference for the phase can be set to another channel to give a more accurate measurement. This does not change the phase result it only helps to reduce the uncertainty due to noise.

The bandwidth of the instrument, usually set to "auto", can be forced to "wide" or "low". When not in auto selection, heterodyning is disabled and the bandwidth is either 5MHz (wide) or 100 KHz (low) to minimise noise when making measurements at low frequencies.

7.2 <u>Datalog</u>

NumetriQ can store and display measurements recorded at regular intervals over a time period. Each data record consists of the elapsed time and up to four data values selected by ZOOM.

The actual interval between data points is governed by the measurement speed and the datalog interval. NumetriQ stores the next available measurement after the datalog interval has elapsed: the actual elapsed time is attached to each datalog record, is displayed with the data on the table or each graph, and returned with each record over the communications (RS232, USB, LAN or GPIB).

The data values may be stored to RAM or directly into either internal non-volatile memory or USB memory stick as each value becomes available. The non-volatile option is useful for acquiring data over long periods, to prevent the loss of data in the event of a power failure.

The RAM datalog can hold up to 32000 records if one value is selected; more than 12000 records if four values are selected. Data that has been stored into RAM may be subsequently transferred to non-volatile memory using the PROG menu.

For high speed data acquisition, the datalog interval may be set to zero so that each measurement is stored. The measurement interval is controlled with the "speed" option in the ACQU menu. Using the "window" option for speed, allows greater control of the measurement interval. In this mode, the display flashes "DATALOG RUNNING" and only shows the acquisition time. The minimum datalog interval depends on the function but is typically 10ms. Note that in all cases the measurement interval is necessarily adjusted to be an integral number of cycles of the measured waveform.

The datalog options are set up with the ACQU menu. The datalog is started with the START key, and stopped with the STOP key unless the store becomes full first. The zero reference for the elapsed time is taken as the first data measurement after START.

The data can be viewed as a table or as individual graphs. Pressing GRAPH steps the graph through the stored parameters. If more than 250 records have been stored, the graph can show the data for the whole period or pressing ZOOM redraws the graph to show 250 records about the cursor. The cursor can be moved in single steps (LEFT or RIGHT) or large steps (UP or DOWN). Pressing UNZOOM shows the whole data gain. Movements of the cursor are synchronised in both the TABLE and GRAPH views.

7.3 <u>SWEEP - Frequency sweep options</u>

All ac measurements using the NumetriQ generator can be swept across a frequency range. The start frequency, stop frequency and number of steps up to 2000 can be specified. The measurements are subjected to the same speed constraints set in the ACQU menu, but the filtering does not apply on each measurement point. If continuous sweep is selected, then the filtering is applied to each successive sweep.

At the end of a sweep the generator may be set to be on, off, or dc only. The settings used are those in the normal generator menu.

The graph normally sets the y axis automatically to the extremes of the measurements (or in FRA mode to 20dB/decade of frequency) but the axis can be fixed if required. The graph of the second parameter (usually phase) can also be independently manually set.

A vertical marker can be placed on the graph to reference a specific frequency.

Each frequency point is an entirely new measurement and autoranging is restarted (if enabled). For the fastest possible sweeps, select manual ranging. As each frequency point is a new measurement, filtering has no effect on a single sweep, but fixed time filtering can be applied independently on each frequency point if repeat sweep in selected.

For maximum sweep speed, particularly when using a large number of points, there is a "fast sweep" mode which disables all non-essential functions, including the display, during the sweep. In this mode the display is blank except for a flashing message "ACQUIRING SWEEP DATA" until the full sweep has been completed when

normal display functions are restored. This mode is automatically selected when a user defined window of less than 100ms has been set.

7.4 <u>TRIM - Trim function</u>

The trim function on NumetriQ is a powerful and versatile feature that allows closed loop control of the generator amplitude. It allows a specific measurement from CH1, CH2 or CH3, if fitted, and the generator output will be adjusted to maintain the measured voltage or current. This allows the excitation level to be controlled over changing conditions such as a frequency sweep.

At each measurement point, the measured level is checked against the specified level and tolerance; if an adjustment is needed the data is discarded and a new measurement made at the new output level. The user is alerted to the adjustment by an audible beep.

Particularly important in control loop analysis, where it is sometimes referred to as amplitude compression, it prevents the control loop being overdriven as the frequency changes.

It is also useful in a more general case where test levels are specified.

Note that when dBm mode level control is selected, the trim level is entered as dBm but the tolerance remains a linear percentage of the actual voltage not the logarithmic dBm measure.

8 Output control

The output for the signal generator is digitally synthesised at an update rate of 150Msamples/s. With the output filtering, this gives a good sinewave waveform, even at 35MHz, while preserving very accurate frequency control.

The output amplitude is controlled in 2 stages – a fine control with 10 bit resolution, with coarse control with 5 steps. This gives 10mV resolution at high output levels and 1mV resolution at low output levels.

The maximum output available from the generator is a function of frequency:

max frequency	output leve	el into 50 Ω
MHz	peak V	rms V
1	7.5	5
5	5	3.5
10	3	2
15	2	1.4
20	1.5	1
25	1.2	0.8
30	1	0.7
35	0.75	0.5
40	0.6	0.5
50	0.4	0.25

An offset may be added to any output to bias the signal or to null out any dc present with a resolution of +/-10mV.

The LEFT and RIGHT keys adjust the frequency of the generator by a fixed increment stored via the STEP menu; the UP and DOWN keys adjust the amplitude (except for

the harmonic analyser and power analyser where UP and DOWN step the selected harmonic).

The generator output may be set to be on, off, or dc only.

8.1 <u>Generator specifications</u>

General		
accuracy	frequency ±0.05%	
	amplitude ±5% (10% > 50MHz)	
accuracy (with	amplitude ±1% < 10MHz	
trim)		
output impedance	$50\Omega \pm 2\%$	
output voltage	±15V peak	
Offset	±10V peak maximum	
waveforms	sine, square, triangle, sawtooth, pulse	
	and white noise	
frequency	10uHz to 50MHz	
output control	10mV to 2mV steps	
Туре	direct digital synthesis	
update rate	210MHz	
DAC resolution	14 bit	
phase	48 bit	
accumulator		

9 Input channels

The two or three input channels are fully isolated from each other and earth. The two channels are controlled independently but sampled synchronously.

Each input channel may be selected to be: direct external shunt external attenuator

If the external shunt option is selected, the data is scaled by the shunt value (entered under the relevant channel menu) and the units are displayed in Amps. Any resistor can be used as a shunt, or precision low inductance current shunts are available as accessories. Current transformers can be used if fitted with an appropriate burden resistor.

Note that the external shunt input polarity is reversed compared to that of the voltage input: ie the - input becomes non-inverting and the + input becomes inverting. This is so that the capacitance to ground of the probe cable screen is driven with the lower source impedance in order to minimise errors at high frequency.

Note that some modes force the input channels to be voltage or current automatically, eg. the power meter defaults to channel 1 as voltage and channel 2 as current. This automatic selection can be overridden if required.

The input ranges have nominal full scale values set with a ratio of $1:\sqrt{10}$ from 3mV to 300V and a top range of 500V. This gives the following ranges:

PSM3750 user manual

range	reference	nominal full scale
1	3mV	3.16mV
2	10mV	10mV
3	30mV	31.6mV
4	100mV	100mV
5	300mV	316mV
6	1V	1V
7	3V	3.16V
8	10V	10V
9	30V	31.6V
10	100V	100V
11	300V	316V
12	500V	1000V

Because of slew rate limitations of the input amplifiers, the maximum input signal that can be accurately measured varies with frequency:

frequency	max inp	out level
MHz	peak V	rms V
5	500	350
10	300	200
15	200	140
20	150	100
25	120	80
30	100	70
35	75	50
40	50	35
50	40	25

The input ranges may be selected manually, or by autoranging (default). The start range for autoranging may be selected if it is known that the signal will not be below a certain level.

There is also an option to autorange 'up only' so that a test may be carried out to find the highest range. Once the highest range has been determined, the range can be set to manual and the measurement made without losing any data due to range changing. Pressing the HOME key (or sending *TRG) restarts the autoranging from the selected minimum range.

When in an input channel menu, the ZERO key provides a quick way to lock and unlock the range. When no flashing box is visible in the input channel menu and autoranging is selected, pressing the ZERO key selects the range that the instrument is currently using and sets the autoranging to manual, thus locking the range and preventing further autoranging. Pressing the ZERO key again returns to full autoranging from the bottom range.

For most measurement functions full autoranging is the most suitable option but some applications, such as where transient events are occurring, are more reliable with manual ranging. Manual ranging (or up-only autoranging) is essential for low frequency measurements.

For measuring signals that are biased on a dc level (such as an amplifier operating on a single supply or the output of a dc PSU), ac coupling can be used. AC+DC coupling is the normal option and should be used where possible.

A scaling factor can be entered for each channel for use with attenuators such as x10 oscilloscope probes. A nominal value can be entered or the attenuation factor of the probe can be measured and the precise value entered. The measured voltage will be displayed after multiplication by the scale factor. The scale factor can be set automatically by pressing TRIG when in an input channel menu. For example, with a x10 oscilloscope probe on channel 1 input, a x1 probe on channel 2 input and both probes connected to the same voltage; press CH1 to invoke the input menu for channel 1 then press TRIG and the scale factor for channel 1 is computed so that channel 1 reads the same as channel 2. Note that when using external divider probes to increase the maximum input voltage it is important to use active probes if accurately measuring dc. This because the dc input impedance is different from the ac input impedance. When using passive probes the dc would read about 10% high.

If the channel has been set for use with an external shunt then the value of the shunt can be entered.

The secondary channel has a control to adjust the gain so that common mode rejection may be maximised when using oscilloscope probes.

9.1 <u>Trimming x10 oscilloscope probes</u>

To minimise the loading effects at high frequencies, x10 oscilloscope probes can be used with NumetriQ. For optimum performance, the probes need to be trimmed to match the input capacitance of the instrument and the probes need to be corrected for gain errors. A small plastic screwdriver is provided with each probe for this purpose. In all, there are three processes that must be carried out to optimise the performance:

probe trim probe scaling

Connect the instrument output across a convenient resistor (anything above 1k) using the supplied BNC to crocodile clip output lead. Connect the probes from the input channels across the resistor. Observe the colour of which probe connects to each of the four input terminals for future use.

Press OUT and set the generator to 1kHz squarewave with 2V amplitude. Press HARM to invoke harmonic analyser mode and select third harmonic. Set all probes to x1.

To trim the probes connected to the main inputs.

The measured third harmonic should read 33.33% +/-0.05%. Select x10 on one of the probes and adjust the trimmer in the body of the probe until the third harmonic again reads the same value. Switch the probe back to x1 and verify that the third harmonic reads the same. Repeat the adjustment if necessary. Select x10 on the other probe and adjust in the same way. To verify the adjustment at 25th frequency, select the harmonic higher for measurement. The reading should be 4.00% +/-0.5% in both x1 and x10 settings.

To adjust for the tolerance within the probes (typically 1%), the main inputs can be scaled and the secondary inputs can be adjusted. Press OUT and set 1kHz sinewave, 2V amplitude; and press FRA to invoke frequency response analyser.

To adjust for tolerance within the probes connected to the main inputs:

With both probes set to x1 check that the measured magnitudes are about the same. Set the probe connected to CH1 to x10 and set the probe connected to CH2 to x1. Press CH1 then TRIG – the scaling factor for channel 1 will be automatically adjusted to a number about 10. Press HOME to exit the menu and observe that the readings for CH1 and CH2 are again about the same.

Set the probe connected to CH1 to x1 and set the probe connected to CH2 to x10. Press CH2 then TRIG – the scaling factor for channel 2 will be automatically adjusted to a number about 10. Press HOME to exit the menu and observe that the readings for CH1 and CH2 are again about the same.

If you have a three channel instrument set the probe connected to CH1 to x1 and set the probe connected to CH2 to x10. Press CH2 then RIGHT to access the CH3 menu. Press TRIG and the scaling factor for channel 3 will be automatically adjusted to a number about 10. Press HOME to exit the menu and observe that the readings for CH1 and CH3 are again about the same. 10 True RMS Voltmeter

The RMS voltmeter measures the total rms of the signal present at the input terminals to the bandwidth of the instrument (>1MHz). Care must be taken when measuring low signal levels to minimise noise pick on the input leads.

The RMS voltmeter measures the elementary values:

rms dc peak surge mean

And derives the values: ac, dBm, crest factor and form factor.

The rms value of a periodic waveform, $v(\phi)$, is given by:

rms =
$$\sqrt{\left[\begin{array}{c} 1/2\pi \int v^2(\phi) d\phi \end{array}\right]}$$

For a sampled signal, the formula becomes:

rms =
$$\sqrt{\left[\frac{1}{n} \sum_{i=0}^{i=n-1} v^{2}[i] \right]}$$

Where n is the number of samples for an integral number of complete cycles of the input waveform.

These are fundamental definitions that are valid for all waveshapes. For a pure sinewave, the formulae equate to peak/ $\sqrt{2}$, but this cannot be applied to other waveshapes. NumetriQ computes the true rms value from the fundamental definition for sampled data.

The dc present is given by:

$$dc = 1/2\pi \int_{0}^{2\pi} v(\phi) d\phi$$

For a sampled signal, the formula becomes:

$$dc = 1/n \sum_{i=0}^{i=n-1} v[i]$$

Where n is the number of samples for an integral number of complete cycles of the input waveform.

Having computed the true rms and the dc component, the ac component can be derived from:

$$rms^2 = ac^2 + dc^2 = ac^2 - dc^2$$

The ac component is also expressed in dB referred to 1mW into 600Ω (dBm):

dBm = 20 log (Vac/Vref)
where Vref =
$$\sqrt{(1mW \times 600\Omega)}$$

or 20 log (Iac/Iref)
where Iref = $\sqrt{(1mW / 600\Omega)}$

The peak measurement is simply the value with the largest magnitude. Positive and negative peaks are independently filtered then the result with the largest magnitude is taken as the peak value. In order to measure surge conditions, the maximum instantaneous peak value (unfiltered) is also recorded. It is important that NumetriQ does not autorange while measuring surge – either set the range to manual or repeat the test with ranging set to up only. To reset the maximum, press START.

Crest factor is derived from the peak and rms: cf = peak / rms

The rectified mean measurement is given by:

mean =
$$1/2\pi \int_{0}^{2\pi} |v(\phi)| d\phi$$

For a sampled signal, the formula becomes:

mean =
$$1/n \sum_{i=0}^{i=n-1} |v[i]|$$

The mean is then normalised to give the same value as rms for a pure sinewave:

Normalised mean = mean x $\pi/2\sqrt{2}$

Form factor is derived from the normalised mean and rms: ff = mean / rms

The measurements are computed over rectangular windows with no gaps. The processing power of the DSP allows the measurements to be made in real time without missing any samples. In this way, the measured rms is a true value even if the signal is fluctuating. The only occasion when data is missed is when an autozero measurement is requested – this can be disabled in the SYSTEM OPTIONS menu if required.

The ZOOM function can be used to select any combination of up to four parameters from the display.

Note that the wideband nature of true rms measurements prevents the use of heterodyning so the frequency range of the measurement is limited to 5MHz. To minimise noise, there is a 100kHz filter applied by default. To obtain the full bandwidth press ACQU, highlight bandwidth and select "wide".

10.1 <u>RMS voltmeter specification</u>

DVM		
Channels	2 or 3 fully isolated	
Display	5 digits	
measurement	true rms, ac, dc, dBm, peak, cf, surge.	
Coupling	ac or ac+dc	
frequency	DC to 5MHz	
	(heterodyning not available)	
ac coupling cut off	~1.5Hz (–3dB)	
max input	±500V peak	
input ranges	*300mV, *1V, *3V, *10V, *= High	
	Voltage Attenuator. 500V, 300V,	
	100V, 30V, 10V, 3V, 1V, 300mV,	
	100mV, 30mV, 10mV, 3mV	
Ranging	full auto, up only, or manual	
input impedance	1M // 30pF (exc. leads)	
accuracy (ac)	0.075% range + 0.075% reading +	
	0.1mV <1kHz	
	above + 0.003%/kHz < 5MHz	
accuracy (dc)	0.1% range + 0.1% reading + 0.5mV	
CMRR (typical)	160dB @ 230V 50Hz	
	140dB @ 100V 1kHz	
	70dB @ 10V 1MHz	
time constant	0.2s, 1.5s or 12s	

Conditions:

23°C +/- 5°C ambient temperature instrument allowed to warm up for \geq 30 minutes Sinewave slow speed, normal filtering ac+dc coupling autoranging or manual ranging \geq 1/3 range

11 Frequency response analyser

NumetriQ measures the gain and phase of channel 2 relative to channel 1 using a discrete Fourier transform (DFT) algorithm at the fundamental frequency.

The DFT technique can measure phase as well as magnitude and is inherently good at rejecting noise – it is much more reliable than measuring the rms at one point relative to another point.

The circuit can be characterised by computing the gain and phase at a number of points over a frequency range. This gives results that show the transfer function of the circuit as a graph on the display.

The DFT analysis yields two components – in-phase and quadrature, or 'a' and 'b' values – from which the magnitude and phase can be derived.

Considering the components at the fundamental frequency:

The fundamental in-phase and quadrature values of a periodic waveform, $v(\phi)$, are given by:

$$a_1 = 1/\pi \int_{0}^{2\pi} v(\phi) .\cos(\phi) d\phi$$

$$b_{1} = 1/\pi \int_{0}^{2\pi} v(\phi) . \sin(\phi) d\phi$$

For a sampled signal, the formulae become:

$$a_1 = 1/n \sum_{i=0}^{i=n-1} v[i].cos(2\pi ci/n)$$

$$b_1 = 1/n \sum_{i=0}^{i=n-1} v[i].sin(2\pi ci/n)$$

Where n is the number of samples for an integral number of complete cycles of the input waveform, and c are the number of cycles.

Having computed the real and quadrature components, the magnitude and phase of each channel can be derived:

mag =
$$\sqrt{(a_1^2 + b_1^2)}$$

 $\theta = \tan^{-1}(b_1/a_1)$

The relative gain and phase of the circuitry under test at that particular frequency is derived from the real and quadrature components by vector division:

vector gain = $(a + jb) \{ch2\} / (a + jb) \{ch1\}$

gain = magnitude (vector gain)

phase = $tan^{-1}(b/a \text{ (vector gain)})$

The gain is usually quoted in dB:

 $dB = 20 \log_{10}(gain)$

To look at differences in gain from a nominal value, an offset gain can be applied either manually or by pressing ZERO.

Offset gain = measured dB - offset dB

The filtering is applied to the real and quadrature components individually, rather than the derived magnitude and phase values. This gives superior results as any noise contribution to the components would have random phase and therefore would be reduced by filtering.

NumetriQ can operate either in real time mode at a single frequency where the gain and phase are filtered and updated on the display; or it can sweep a range of frequencies and present the results as a table or graphs of gain and phase.

The frequency points to be measured are specified with three parameters:

number of steps start frequency end frequency

NumetriQ computes a multiplying factor that it applies to the start frequency for the specified number of steps. Note that due to compound multiplication it is unlikely that the end frequency will be exactly that programmed. The frequency sweep is initiated by the START key, and when completed the data can be viewed as a table or graphs.

Following a sweep on a control loop, the gain and phase margins can be computed and displayed on the graph.

The window over which the measurements are computed is adjusted to give an integral number of cycles of the input waveform. In real time mode the results from each window are passed through a digital filter equivalent to a first order RC low pass filter; in sweep mode each result comprises a single window without any filtering unless repeat sweep is selected.

The top of the vertical axis for the graph is normally set to be the highest measured value during the sweep. The bottom of the vertical axis is normally either set to the lowest measured value or the result of the highest value less 20dB/decade of frequency. The vertical axis can be fixed to a manual scale using the menus.

The ZOOM function can be used to select up to four parameters from the display when in real time mode. It has no function following a sweep.

Following a sweep the GRAPH key selects between:

Graph of gain v frequency

Graph of phase v frequency

Graph of gain and phase v frequency

If three channels are being used then the three graphs above are repeated for computation 2 (as selected in the main FRA menu).

Pressing HOME or TRIG restarts the real time measurement at the selected frequency.

Although it is most usual to use the NumetriQ generator when performing gain/phase analysis, there may be circumstances where this is impractical, for example measuring across a transformer under load. In this case, turn off the NumetriQ generator (OUT menu) and the frequency reference for the analysis is measured from channel 1. Provided that the signal is clean enough for an accurate frequency measurement (and for DFT analysis the frequency does need to be accurately known), then the gain and phase can be measured reliably.

When using an external frequency reference there can be no sweep function.

11.2 <u>Quick start guide to Feedback Loop Analysis</u>

This section is aimed as a helpful guide to enable you to set up your PSM3750 with the aid of screenshots and instructions with respect to Feedback Loop Analysis.

	ACQUISITION CONTROL
input speed cycles smoothing smoothing response phase reference bandwidth	2 channels fast 1 normal auto reset channel 1 auto
	advanced options >

Setting Input Channels to be used.

Action	Result
Press 'ACQU'	Acquisition Control Menu appears
Press '↓'	Flashing Red Box appears around the Input Channels selection
Press '→'	Flashing Red Box appears around 2 channels / 3 channels
Press '↓'	Select 2 Channel Option
Press 'ENTER'	2 Channels have been selected as the Input
Press 'HOME'	Flashing Red Box now disappears
Press 'HOME'	Display returns to measurement window

Setting the Amplitude and Output to On.

OUTPUT	
waveform	sinewave
amplitude control	V
amplitude	300.00 <i>m</i> //pk
amplitude step size	1.1000 times
offset	+0.0000 <i>V</i>
frequency	16.000k Hz
step type	logarithmic
frequency step size	2.0000 times
phase control	off
output	on

<u>Action</u>	Result
Press 'OUT'	Output Control Menu appears
Press '↓' 3 TIMES	Flashing Red Box appears around the Amplitude Setting
Press '300m'	300mv now appears in the Amplitude Option
Press 'ENTER'	300mv is selected as the Amplitude
Press '↓' 7 TIMES	Flashing Red Box appears around the Output Mode
Press '→'	Off, On, DC Only, options appear on screen
Press '↓'	Select 'On' option
Press 'ENTER'	Output On is now selected
Press 'HOME'	Flashing Red Box will now disappear
Press 'HOME'	Display returns to measurement window

Gain and Phase Margins: Enable / Disable

MEASUREMENT SETTINGS		
mode	frequency response analyzer	
speed	fast	
smoothing	normal	
smoothing response	auto reset	
computation 1	ch2/ch1	
offset	0.0000 dB	
gain/phase margins	enabled	
graph	phase	

<u>Action</u>	Result
Press 'MODE'	Measurement Settings Control Menu appears
Press '↓' 7 TIMES	Flashing Red Box appears around the Gain / Phase selection
Press '→'	Flashing Red Box appears around disabled / enabled options
Press '↓'	Select Enabled Option
Press 'ENTER'	Enabled Option has now been selected for the Gain / Phase margins
Press 'HOME'	Flashing Red Box now disappears
Press 'HOME'	Display returns to measurement window

Setting Channels 1&2 Input Ranges & Coupling

CHANNEL 1 RANGING		
input autoranging minimum range scale factor coupling	direct full autorange 3 <i>ml/</i> +1.0000 ac	
channel 2 ranging >		

Action	Result
Press 'CH 1'	Channel 1 Control Menu appears
Press '↓' 5 TIMES	Flashing Red Box appears around the Coupling selection
Press '→'	Flashing Red Box appears around ac+dc, ac options
Press '↓'	Select ac only
Press 'ENTER'	Flashing Red Box appears around ac selection
Press 'HOME'	Flashing Red Box now disappears and ac is selected
Press 'HOME'	Display returns to measurement window

To change any of the other Input settings follow steps as above to enable the parameters to be amended

PSM3750 user manual

CHANNEL 2 RANGING	
input autoranging minimum range scale factor coupling	direct full autorange 3 <i>mV</i> + <u>1.0</u> 000 ac
	< channel 1 ranging

Action	Result
Press 'CH 2'	Channel 2 Control Menu appears
Press '↓' 5 TIMES	Flashing Red Box appears around the Coupling selection
Press '→'	Flashing Red Box appears around ac+dc, ac options
Press '↓'	Select ac only
Press 'ENTER'	Flashing Red Box appears around ac selection
Press 'HOME'	Flashing Red Box now disappears and ac is selected
Press 'HOME'	Display returns to measurement window

Frequency Sweep Data Settings

FREQUENCY SWEEP CONTROL

sweep start	100.00 Hz
sweep end	250.00k Hz
steps	100
steps	log
sweep	single
generator when complete	off
graph 1 scaling	auto
graph 2 scaling	auto
frequency marker	off

<u>Action</u>

Result

Press 'SWEEP'	Frequency Sweep Control Menu appears
Press '↓'	Flashing Red Box appears around the Sweep Start selection
	Sweep Start now requires setting
Press '100'	100 now appears in the Sweep Start Option
Press 'ENTER'	100Hz has now been selected for the Frequency Sweep start Point
Press '↓'	Flashing Red Box appears around Sweep End selection
	Sweep End now requires setting
Press '250k'	250k now appears in the Sweep End Option
Press 'ENTER'	250 KHz has now been selected for the Frequency Sweep end Point
Press '↓'	Steps Option now selected
	Steps for plotting Frequency now requires setting
Press '100'	100 now appears in the Steps Option
Press 'ENTER'	100 Steps has now been selected for Frequency Plotting
Press 'HOME'	Display returns to measurement window
PSM3750 user manual

Perform Sweep and Review.



Action	Result
Press 'SWEEP'	Frequency Sweep Control Menu appears
	Check Sweep data parameters (as Frequency Sweep screen)
Press 'SWEEP'	Display returns to measurement screen
Press 'START'	Frequency Sweep will begin
Press 'GRAPH'	View all data from sweep, keep pressing Graph to view more results
Press 'TABLE'	View data from all plotting points
Press 'REAL TIME'	Display returns to measurement window

PSM3750 user manual

Screen Print Options.

REMOTE SETTINGS	
resolution interface baud rate recall with program screen print	normal RS232 19200 off USB memory stick
	USB device ready

Action	Result
Press 'COMMS'	Remote Settings Control Menu appears
Press '↓' 5 TIMES	Flashing Red Box appears around the Screen Print selection
Press '→'	Flashing Red Box appears around disabled, RS232, USB memory stick
Press '↓'	Select 'USB memory stick' only
Press 'HOME'	USB memory stick mode has now been selected for screen prints
Press 'HOME'	Display returns to measurement window

Frequency response analyser specification

Frequency response (gain/phase) analyser		
frequency	10uHz to 50MHz (own generator)	
	20mHz to 5MHz (external sc	ource)
max input	±500V peak	
input ranges	*300mV, *1V, *3V, *10V, *	= High
	Voltage Attenuator. 500V, 3	300V,
	100V, 30V, 10V, 3V, 1V, 300	0mV,
	100mV, 30mV, 10mV, 3mV	
ranging	full auto, up only, or manual	I
input impedance	1M Ohm // 30pF (exc. leads)
magnitude	0.075% range + 0.075% rea	ading +
accuracy	50uV <10kHz	
(auto)	as above + 0.0003%/kHz	< 50MHz
(wide)	as above + 0.003%/kHz	< 5MHz
gain accuracy	0.01 dB	< 10kHz
(auto)	0.01 dB + 0.0001 dB/kHz	< 5MHz
	0.31 dB + 0.00004 dB/kHz	< 50MHz
(wide)	0.01 dB + 0.001 dB/kHz	< 5MHz
phase accuracy	0.025°	< 10kHz
(auto)	0.05° + 0.00025°/kHz	< 50MHz
(wide)	0.025° + 0.002°/kHz	< 5MHz
CMRR (typical)	160dB @ 230V 50Hz	
	140dB @ 100V 1kHz	
	70dB @ 10V 1MHz	
sweep step rate	1/20s, 1/3s or 2.5s (approx.	.)

Conditions:

 $23^{\circ}C$ +/- 5°C ambient temperature instrument allowed to warm up for \geq 30 minutes ac+dc coupling autoranging or manual ranging \geq 1/3 range signals > 10mV

12 Phase angle voltmeter (vector voltmeter)

A phase angle voltmeter (or vector voltmeter, or phase sensitive voltmeter) measures the signal at one input compared to the phase of the signal at a reference input. The results may be expressed as magnitude and phase, or as separate in-phase and quadrature components.

NumetriQ measures the in-phase and quadrature components at the fundamental frequency using DFT analysis as described in the section on frequency response analysis. CH2, the measurement input, is phase referred to CH1, the reference input. The individual components are filtered separately to minimise the effects of noise, which would have random phase and would therefore be filtered out. The true rms of the input signals is also computed.

CH1 and CH2 may be voltage inputs or may use external shunts.

From the phase referred fundamental components, (a + jb), the following results can be derived:

magnitude	$= \sqrt{(a^2 + b^2)}$
phase	= tan ⁻¹ (b/a)
tan ø	= b/a
in-phase ratio	= a2 / a1
LVDT (diff)	= scale * a2 / a1
LVDT (ratio)	= scale * (m1-m2) / (m1+m2)

Where a1 and a2 are the in-phase components, and m1 and m2 are the magnitudes, of the signals present at ch1 and ch2 respectively.

The parameter of interest is selected via the PAV or MODE menu. The frequency and phase are always displayed.

A null meter display may be selected via the PAV menu to allow adjustment of a circuit for minimum phase or component. The parameter on the display depends on the selected component:

parameter	display	null meter
in-phase		in-phase
quadrature		quadrature
tan∳	tan∳	tan∳
magnitude	magnitude	magnitude
phase	phase	
rms	rms	rms2
rms2/1	rms2/rms1	rms2/rms1
in-phase ratio	in-phase ratio	in-phase ratio
LVDT diff	LVDT	LVDT
LVDT ratio	LVDT	LVDT

The null meter may be manually ranged or will automatically range as the signal varies. When manually ranging, ZOOM+ and ZOOM- adjust the range by a decade.

There is a phase offset option that applies a vector rotation of a user selectable phase shift to the CH2 input data.

NumetriQ can operate either in real time mode at a single frequency where the measurements are filtered and updated on the display; or it can sweep a range of frequencies and present the results as a table or graphs. Before performing a sweep, the desired parameter must be selected.

The frequency points to be measured are specified with three parameters:

number of steps start frequency end frequency NumetriQ computes a multiplying factor that it applies to the start frequency for the specified number of steps. Note that due to compound multiplication it is unlikely that the end frequency will be exactly that programmed. The frequency sweep is initiated by the START key, and when completed the data can be viewed as a table or graphs or printed out.

The window over which the measurements are computed is adjusted to give an integral number of cycles of the input waveform. In real time mode the results from each window are passed through a digital filter equivalent to a first order RC low pass filter; in sweep mode each result comprises a single window without any filtering.

The ZOOM function can be used to select up to four parameters from the display when in real time mode. It has no function following a sweep.

Although it is most usual to use the NumetriQ generator when making Phase Angle Voltmeter measurements, there may be circumstances where this is impractical, for example measuring LVDT displacement under actual circuit conditions. In this case, turn off the NumetriQ generator (OUT menu) and the frequency reference for the analysis is measured from channel 1. Provided that the signal is clean enough for an accurate frequency measurement (and for DFT analysis the frequency does need to be accurately known), then the measurements can be made reliably.

When using an external frequency reference there can be no sweep function.

Phase angle voltmeter (vector voltmeter)		
frequency	10uHz to 50MHz (own generator)	
	20mHz to 5MHz (external source)	
measurement type	DFT analysis, and true rms	
measurements	Magnitude, Phase, In-Phase &	
	Quadrature components, TanΦ, In-	
	Phase Ratio, LVDT (diff), LVDT (ratio),	
	Rms, Rms Ratio	
phase resolution	0.001°	
tanΦ resolution	0.0001	
other	as FRA	

Conditions:

23°C +/- 5°C ambient temperature instrument allowed to warm up for \geq 30 minutes ac+dc coupling autoranging or manual ranging \geq 1/3 range

13 Power meter

The power meter measures the total power and fundamental power of the signal present at the input terminals to the bandwidth of the instrument (>1MHz). Above 5MHz, only the fundamentals are measured.

One of the inputs must be configured as an external shunt input. The external shunt may be a simple resistor or dedicated high frequency precision shunts are available as accessories. Current transformers and clamps may be used if fitted with a suitable burden resistor. For use at mains voltages, a mains power adaptor incorporating voltage and current transformers is available.

The power meter will operate either from its own generator or, more normally, will use the frequency measured on channel 1 (usually voltage).

The power meter measures the elementary values:

W

V rms

A rms

V fundamental (in-phase and quadrature)

A fundamental (in-phase and quadrature)

V dc

A dc

V harmonic (in-phase and quadrature) A harmonic (in-phase and quadrature) frequency

and derives the following values:

V & A fundamental magnitude VA (true and fundamental) power factor (true and fundamental) fundamental W harmonic W phase shift When the integrator function is activated, the following values are available:

Elapsed time (in hours, minutes and seconds) Watt-hours (true and fundamental) VA hours (true and fundamental) average power factor (true and fundamental) Ampere hours (true and fundamental)

The power dissipated in a load subjected to a periodic voltage, $v(\phi)$, with a current flowing $a(\phi)$, is given by:

$$w = 1/2\pi \int_{0}^{2\pi} v(\phi).a(\phi) d\phi$$

For a sampled signal, the formula becomes:

$$w = 1/n \sum_{i=0}^{i=n-1} v[i].a[i]$$

Where n is the number of samples for an integral number of complete cycles of the input waveform.

These are elementary definitions that are valid for all waveshapes. NumetriQ computes the true watts value from the elementary definition for sampled data. Formulae for the components at the fundamental frequency are given in the section on frequency response analysis; formulae for the harmonic components are given in the section on harmonic analysis.

The formulae for the derived results are: $VA = V_{rms} \times A_{rms}$

power factor	= Watts/VA
fundamental Watts	= V _{real} x A _{real} + V _{quad} x A _{quad}
harmonic Watts	= VH _{real} x AH _{real} + VH _{quad} x AH _{quad}
fundamental VA	$= V_{\text{fund}} \times A_{\text{fund}}$
fund power factor	= W _{fund} / VA _{fund}

In power meter mode, the UP and DOWN key do not adjust the amplitude but step the harmonic number.

The measurements are computed over rectangular windows with no gaps. The processing power of the DSP allows the measurements to be made in real time without missing any samples. In this way, the measured power is a true value even if the signal is fluctuating. The only occasion when data is missed is when an autozero measurement is requested – this can be disabled in the SYSTEM OPTIONS menu.

The high linearity of NumetriQ allows real-time measurements be made on waveforms with periodic bursts such as low standby power PSUs. Use "autorange up" to find the range.

NumetriQ blanks the results when either of the measured rms signals are low compared to the full scale range. This function can be disabled if desired in the SYSTEM menu.

The ZOOM function can be used to select any combination of up to four parameters from the display.

The integrator is started, or reset, by pressing the START key. The Watt hour integration and the Ampere hour integration can be selected to be signed or magnitude. To integrate the total power in terms of heating effect, choose magnitude. If signed integration is selected then the rms current is given the sign of the power before integration. The Ampere hours and Watt hours then reflect the power taken by the load, less any power generated by the load, such as during regenerative braking in battery systems.

13.1 <u>Power meter specification</u>

Power meter		
current input	External shunt or Voltage CT	
display	5 digits	
measurement	W, VA, PF,V,A, - Total, Fundamental	
	and Integrated, Power Harmonics	
coupling	AC+DC, AC(<10VDC), AC(<500VDC)	
frequency	DC & 10mHZ to 5MHz	
	5MHz to 50MHz (fundamentals only)	
ac coupling cut off	~1.5Hz (–3dB)	
max input	±500V peak	
input ranges	300mv* 1v* 3v* 10v* *=High Voltage	
	Attenuator: 500V, 300V, 100V, 30V,	
	10V, 3V, 1V, 300mV, 100mV, 30mV,	
	10mV, 3mV	
ranging	Full Auto, Up Only, or Manual	
input impedance	1M Ohm	
accuracy (ac)	0.1% range + 0.1% reading +external	
	shunt tolerance	
accuracy (dc)	0.2% range + 0.2% reading	
CMRR (typical)	160dB @ 230V 50Hz	
	140dB @ 100V 1kHz	
	/UdB @ 10V 1MHz	
time constant	0.2s, 1.5s or 12s	

Conditions:

23°C +/- 5°C ambient temperature instrument allowed to warm up for \geq 30 minutes sinewave, power factor > 0.7 slow speed, normal filtering ac+dc coupling autoranging or manual ranging \geq 1/3 range tolerance of current shunt to be added

14 <u>LCR meter</u>

In LCR meter mode, channel 1 measures the voltage across the component under test, and channel 2 measures the current through it. To measure the current, channel 2 must be connected across an appropriate external shunt.

The easiest way to use the LCR meter is with the 'IAI – impedance analyser interface' (see accessories) that sits under the NumetriQ and provides 4 wire Kelvin clip connections to the component under test. The IAI provides a choice of four shunts, selectable from the front panel, and buffers the signals to minimise the effects of stray capacitance and inductance.

Measurements can be made without the IAI by simply connecting a series shunt. The shunt chosen must be appropriate for the voltage, the current and the frequency of operation.

There are three manual connection options, "shunt", "divider Zx low", "divider Zx high".



For "shunt" connection, shown above, the current is measured directly across the shunt using CH2 while the voltage across the Zx is measured by CH1. Notice that the positive inputs to both CH1 and CH2 are connected to the midpoint to minimise common mode loading effects.

Then: $Zx = Zs \times CH1 / CH2$



For "divider Zx low" connection, shown above, the total voltage is measured by CH1 and the voltage arising from the potential divider effect of Zs and Zx is measured by CH2. Notice that all the negative terminals are connected together.

Then: Zx = Zs / ((CH1 / CH2) - 1)

The connections for "divider Zx high" are the same as above but with Zx in the high arm of the potential divider and the shunt in the low arm.

Then: Zx = Zs x ((CH1 / CH2) - 1)

NumetriQ measures the real and imaginary components at the fundamental frequency using DFT analysis as described in the section on gain/phase analysis. The frequency may be taken from its own generator or from the circuitry under test.

From the fundamental components of voltage, (a + jb), and those of the current, (c + jd), NumetriQ computes the complex impedance given by:

z = v / i
=
$$(a + jb) / (c + jd)$$

The components of the complex impedance are filtered independently to minimise the effects of noise, which would have random phase and would therefore be filtered out.

The magnitude of the voltage and current are also computed.

From the complex impedance the following parameters can be derived:

ac resistance inductance, capacitance impedance phase tanδ (= real/imaginary) Q factor (= imaginary/real)

Values are displayed for both series and parallel configurations.

Optionally, the values can be expressed as admittance, conductance, and susceptance instead of impedance, resistance and reactance.

If the parameter option in LCR menu is set to 'auto', NumetriQ will display capacitance or inductance according to the phase of the measurement. Alternatively, the display can be forced to capacitance, inductance or impedance.

Capacitance is displayed with $tan\delta$, inductance is displayed with Q factor, and impedance is displayed in its resistive + reactive form and as magnitude. The phase of the impedance is displayed with all options.

The operating conditions for the component under test may be selected manually or NumetriQ will automatically try to find appropriate conditions.

When measuring large electrolytic capacitors, it may be necessary to add an appropriate bias voltage to polarise the electrodes. In this case it may be necessary to select ac coupling in the CH1 menu in order to reliably measure the small ac voltage present.

When measuring small inductance or capacitance, it may be necessary to zero out the stray effects from the test connections. Press ZERO to access the compensation menu. For inductance connect together the test leads to a good short and select "short circuit" – the message 'SHORT CIRCUIT ZERO SET' will be displayed; for capacitance disconnect the test leads and press ZERO – the message 'OPEN CIRCUIT ZERO SET' will be displayed. To remove the zero, press ZERO then press DELETE within 1.5s – the message 'ZERO CLEARED' will be displayed.

For repeated measurements under the same test conditions (eg. production testing of a batch of capacitors) it is possible to compensate for the inherent phase shift of the connection jig. Connect a known reference component to the system, enter the known phase shift of the component as the "phase reference" in the ZERO menu and select "phase adjust". NumetriQ then applies a compensating vector rotation to all subsequent measurements.

NumetriQ can operate either in real time mode at a single frequency where the measurements are filtered and updated on the display; or it can sweep a range of frequencies and present the results as a table or graphs. Before performing a sweep, either series circuit or parallel circuit must be selected.

The frequency points to be measured are specified with three parameters:

number of steps start frequency end frequency

NumetriQ computes a multiplying factor that it applies to the start frequency for the specified number of steps. Note that due to compound multiplication it is unlikely that the end frequency will be exactly that programmed. The frequency sweep is initiated by the START key, and when completed the data can be viewed as a table or graphs or printed out.

The window over which the measurements are computed is adjusted to give an integral number of cycles of the input waveform. In real time mode the results from each window are passed through a digital filter equivalent to a first order RC low pass filter; in sweep mode each result comprises a single window without any filtering unless repeat sweep is selected.

Very good results can be obtained in a reasonable time using the medium speed setting (e.g. 50 points x ~1/3s \approx 17s); for the very best results, use the slow setting (50 points x ~2.5s \approx 125s or 2 minutes, 5 seconds).

The ZOOM function can be used to select up to four parameters from the display when in real time mode. It has no function following a sweep.

Although it is most usual to use the NumetriQ generator when performing LCR measurements, there may be circumstances where this is impractical, for example measuring the inductance of a transformer primary winding under load. In this case, turn off the NumetriQ generator (OUT menu) and the frequency reference for the analysis is measured from channel 1. Provided that the signal is clean enough for an accurate frequency measurement (and for DFT analysis the frequency does need to be accurately known), then the measurements can be made reliably.

When using an external frequency reference there can be no sweep function.

14.1 LCR meter specification

LCR meter		
frequency	10uHz to 50MHz (own generator)	
	20mHz to 50MHz (external source)	
measurement type	DFT analysis	
measurements	L, C, R (ac), Q, tanδ, impedance,	
	phase, admittance	
	series or parallel circuit	
conditions	auto, or manual	
display	numeric values	
	table of sweep results	
	graph of any measurement	
ranges	100pF to 100uf	
(with external	1μH to 100H	
shunt)	1 Ω to 1M Ω	
ranges	1pF to 1000uF	
(with IAI2)	10nH to 10kH	
	1mΩ to 500MΩ	
basic accuracy	0.1% + tolerance of Shunt	
sweep step rate	1/20s, 1/3s or 2.5s (approx.)	

Conditions:

23°C +/- 5°C ambient temperature instrument allowed to warm up for \geq 30 minutes ac+dc coupling autoranging or manual ranging \geq 1/3 range using impedance interface adaptor

15 <u>Harmonic analyser</u>

The NumetriQ harmonic analyser computes multiple DFTs on the input waveforms in real time (refer to the chapter on frequency response analysis for the formulae for DFT analysis).

There are three modes of operation: single harmonic, difference thd, and series thd. In single harmonic mode, the specified harmonic is displayed both in Volts and as a ratio to the fundamental; in either thd mode, the computed thd and a specified harmonic are displayed as a ratio to the fundamental.

In difference thd mode, the thd is computed from the rms and fundamental:

thd =
$$1/h_1 \sqrt{(\text{rms}^2 - h_1^2)}$$

In series thd mode, the thd is computed from a series of up to 64 harmonics.

thd =
$$1/h_1 \sqrt{\sum_{i=2}^{i=n} h_i^2}$$
 where h_i is the ith harmonic

In series mode the magnitude and phase of all the harmonics can be seen as a table or the magnitudes can be displayed as a bargraph which changes in real time with the measurements. When viewing the bargraph, ZOOM+ and ZOOM- change the vertical axis by a factor of 10.

In all cases the harmonics are phase referred to CH1 fundamental so that their in-phase and quadrature components may be separately filtered to minimise noise.

The single harmonic and the thd are expressed relative to the fundamental either as a percentage or in dB, as selected via the HARM menu.

NumetriQ can operate either in real time mode at a single frequency where the measurements are filtered and updated on the display; or it can sweep a range of frequencies and present the results as a table or graphs.

The frequency points to be measured are specified with three parameters:

number of steps start frequency end frequency

NumetriQ computes a multiplying factor that it applies to the start frequency for the specified number of steps. Note that due to compound multiplication it is unlikely that the end frequency will be exactly that programmed. The frequency sweep is initiated by the START key, and when completed the data can be viewed as a table or graphs or printed out.

The window over which the measurements are computed is adjusted to give an integral number of cycles of the input waveform. In real time mode the results from each window are passed through a digital filter equivalent to a first order RC low pass filter; in sweep mode each result comprises a single window without any filtering.

Very good results can be obtained in a reasonable time using the medium speed setting (e.g. 50 points $x \sim 1/3s \cong 17s$); for the very best results, use the slow setting (50 points $x \sim 2.5s \cong 125s$ or 2 minutes, 5 seconds).

The ZOOM function can be used to select up to four parameters from the display when in real time mode. It has no function following a sweep.

Although it is most usual to use the NumetriQ generator when making harmonic measurements, there may be circumstances where this is impractical, for example measuring harmonic currents drawn from the mains. In this case, turn off the NumetriQ generator (OUT menu) and the frequency reference for the analysis is measured from channel 1. Provided that the signal is clean enough for an accurate frequency measurement (and for DFT analysis the frequency does need to be accurately known), then the measurements can be made reliably.

When using an external frequency reference there can be no sweep function.

15.1 <u>Harmonic analyser specification</u>

Harmonic analyser		
fundamental	20mHz to 50MHz (own generator)	
frequency	20mHz to 5MHz (external source)	
harmonic	10uHz to 1MHz	
frequency		
measurement type	multiple DFT analysis	
measurements	single harmonic, differential thd, thd	
	by series of harmonics	
max harmonic	100	
max input	±10V peak	
input ranges	10V*, 3V*, 1V*, 300mV* *= High	
	Voltage Attenuator. 500V, 300V,	
	100V, 30V, 10V, 3V, 1V, 300mv,	
	100mV, 30mV, 10mV, 3mV.	
ranging	full auto, up only, or manual	
input impedance	1M // 30pF (exc. leads)	
magnitude	0.1% of fundamental + 0.01mV +	
accuracy	accuracy of fundamental	
sweep step rate	1/20s, 1/3s or 2.5s (approx.)	

Conditions:

 $23^{\circ}C$ +/- 5°C ambient temperature instrument allowed to warm up for \geq 30 minutes ac+dc coupling autoranging or manual ranging \geq 1/3 range

16 Transformer analyser

The transformer analyser mode allows a comprehensive set of measurements to be performed on a transformer at a single frequency or automatically swept over a range of frequencies.

The tests available are: turns ratio inductance leakage inductance ac resistance and Q factor dc resistance interwinding capacitance magnetising current insertion loss return loss single harmonic distortion total harmonic distortion longitudinal balance

The transformer analyser function is invoked, and the test selected, by the MODE key.

The easiest way to connect to the transformer in the various configurations for the different test is to use the transformer analyser fixture (see accessories) that connects to the NumetriQ BNC connectors via the BNC splitters and also to the NumetriQ extension port. Using the fixture, with appropriate source and load resistors, the test configuration and winding selection is selectable from the front panel. Active buffers within the fixture minimise the effects of stray capacitance and inductance.

For higher frequency operation, or if the automatic fixture is not available, make the connections manually with x10 oscilloscope probes (set the fixture option in the AUX menu to 'none'). The operating conditions for the component under test may be selected manually or for some tests (such as turns ratio) NumetriQ will automatically try to find appropriate conditions.

NumetriQ can operate either in real time mode at a single frequency where the measurements are filtered and updated on the display; or it can sweep a range of frequencies and present the results as a table or graphs. Before performing a sweep, the required test must be selected.

The ZOOM function can be used to select up to four parameters from the display when in real time mode. It has no function following a sweep.

Although it is most usual to use the NumetriQ generator when performing transformer analysis, there may be circumstances where this is impractical, for example measuring the turns ratio of a transformer under load. In this case, turn off the NumetriQ generator (OUT menu) and the frequency reference for the analysis is measured from channel 1. Provided that the signal is clean enough for an accurate frequency measurement (and for DFT analysis the frequency does need to be accurately known), then the measurements can be made reliably.

When using an external frequency reference there can be no sweep function.

16.1 <u>Turns ratio</u>

Turns ratio is computed from the real part of the complex ratio of CH2 divided by CH1 using DFT analysis at the fundamental frequency (refer to the chapter on gain/phase analysis for the formulae for DFT analysis). This technique gives good results even on 'lossy' transformers.

The polarity of the windings is indicated by a positive turns ratio for in phase windings and negative ratio for inverted windings.

A nominal number of turns may be entered using the SETUP menu if known and NumetriQ will then also display the computed number of turns.

As the inputs are independent of the output it is possible to energise a third winding when measuring turns ratio, or only two windings may be used.

To manually connect a transformer for turns ratio, connect the NumetriQ output to the winding to be energised, and the inputs to the two windings for the ratio.

Note that when using the transformer analyser fixture, the transformer is always energised through the source resistance.

Pressing ZERO makes the turns ratio read 1:1, and the computed number of turns equal to the value entered via SETUP. This allows accurate testing of transformers or chokes against a known good reference. Press ZERO followed by DELETE to restore true turns ratio measurement.

16.2 Inductance & leakage inductance

The inductance of a winding is computed from the complex ratio of CH1 (voltage across the winding) divided by CH2 (current through the winding) using DFT analysis at the fundamental frequency (refer to the chapter on gain/phase analysis for the formulae for DFT analysis).

CH2 is forced to be external shunt input – enter the value of the external shunt as the source resistance via the SETUP menu.

To manually connect a transformer for inductance measurement, connect an appropriate source resistance in series with the winding and connect the NumetriQ output across the series combination of the source resistance and winding. Connect the CH1 input across the winding to measure the voltage, and CH2 across the series resistance (note that the polarity of external shunt input is the opposite of that for voltage). Leave all other windings open.

To manually measure leakage inductance, use the same set up as for inductance but short the other windings.

When using the transformer analyser fixture, the connections for inductance or leakage inductance are made automatically by relays.

When measuring small inductance it may be necessary to zero out stray effects by replacing the winding with a good short and pressing ZERO. The message 'ZERO SET' will be displayed. To remove the effect of the zero press 'ZERO' followed 'DELETE' within 1.5s and the message 'ZERO CLEARED' will be displayed.

16.3 <u>AC resistance and Q factor</u>

AC resistance is measured the same way as inductance with CH1 monitoring the voltage across the winding, and CH2 monitoring the current through it via the external shunt (source resistance).

The Q factor measurement is an effective way of detecting a shorted turn – either on a transformer, or on a choke when using the transformer analyser fixture TAF02. When using suitable conditions (often very different from the normal operating conditions of the device under test) the Q factor changes dramatically when a shorted turn is present.

16.4 DC resistance

DC resistance is measured with the same circuit arrangement as inductance and ac resistance, but dc signals are used (refer to the chapter on the rms voltmeter for the formulae for dc analysis).

16.5 <u>Interwinding capacitance</u>

The interwinding capacitance of a transformer is computed from the complex ratio of CH1 (voltage across the transformer) divided by CH2 (current through the transformer) using DFT analysis at the fundamental frequency (refer to the chapter on gain/phase analysis for the formulae for DFT analysis).

CH2 is forced to be external shunt input – enter the value of the external shunt as the source resistance via the SETUP menu.

To manually connect a transformer for interwinding capacitance measurement, connect an appropriate source resistance in series with one winding and connect the NumetriQ output across the transformer from the series resistance to another winding. Connect the CH1 input across the transformer from one winding to the other to measure the voltage across the windings, and CH2 across the series resistance (note that the polarity of external shunt input is the opposite of that for voltage).

When using the transformer analyser fixture, the connections for interwinding capacitance are made automatically by relays.

When measuring small capacitance it may be necessary to zero out stray effects by disconnecting the transformer and pressing ZERO – the message 'ZERO SET' will be displayed. The transformer analyser fixture TAF01, has a stray capacitance of around 60pF that can be zeroed out this way. To remove the effect of the zero press 'ZERO' followed 'DELETE' within 1.5s and the message 'ZERO CLEARED' will be displayed.

16.6 <u>Magnetising current</u>

The magnetising current is the current drawn by the primary, energised under normal operating conditions but without any secondary load. It is typically measured on power transformers rather than signal transformers so although the transformer analyser fixture, TAF01, will select appropriate relays to make the measurement it is more common that a manual connection or a custom fixture would be used.

The magnetising current is measured as the true rms value (refer to the chapter on the rms voltmeter for the formulae for rms analysis) so it will include all distortion components.

To manually connect a transformer for magnetising current measurement, connect an appropriate shunt in series with the primary. When selecting the shunt, bear in mind the current that it must pass, the resulting voltage drop across it, and the power that will be dissipated in it. Connect CH1 directly across the primary winding using a pair of appropriate probes, and CH2 across the series resistance with a second pair of probes(note that the polarity of external shunt input is the opposite of that for voltage). Ensure that all probes and the series resistance are appropriate for the voltage, the current and the frequency of operation.

Energise the primary so that the voltage seen at the primary after the series resistance is the normal operating voltage.

16.7 <u>Return loss</u>

Return loss is a measure of impedance mismatch in signal transformers that are terminated with the design load resistance.

The secondary winding is terminated with the appropriate load resistance and the primary is energised via a source resistance that is equal to the resistance that should be reflected back from the secondary (load resistance * $(turns ratio)^2$). The impedance looking into the primary is measured.

If z is the complex impedance measured at the primary, and R is the source resistance then the return loss is given by:

return loss = $|\mathbf{z} + \mathbf{R}| / |\mathbf{z} - \mathbf{R}|$

Return loss is usually expressed in dB:

$$= 20 \log (| \mathbf{z} + \mathbf{R} | / | \mathbf{z} - \mathbf{R} |) d\mathbf{B}$$

As a figure of merit, a higher value of return loss indicates a better transformer.

The circuit arrangement for return loss is the same as that for inductance measurement except that the secondary is terminated with the appropriate load resistance.

As the value of the load source resistance, R, is used in the computation, it is important that this value be entered via the MODE menu.

16.8 Insertion loss

Insertion loss is a measure of power loss due to impedance mismatch in signal transformers that are terminated with the design load resistance.

The secondary winding is terminated with the appropriate load resistance and the primary is energised via a source resistance that is equal to the resistance that should be reflected back from the secondary (load resistance * (turns ratio)²). The voltage energising the series resistance and primary winding is measured and the voltage on the secondary is measured.

If Rs is the source resistance, the power into the transformer is computed as:

Win = $Vin^2 / 4 Rs$

If RI is the load resistance, the power out is computed as:

Wout = Vout² / RI

Insertion loss then is given by:

Insertion loss = Win / Wout = (Vin / Vout)² . RI / 4 Rs

Insertion loss is usually expressed in dB:

= 10 log ((Vin / Vout)² . RI / 4 Rs) dB

As a figure of merit, a lower value of insertion loss indicates a better transformer.

To manually connect a transformer for insertion loss measurement, fit the appropriate source resistance in series with the primary winding then connect the NumetriQ output and CH1 differential input across the series combination of the source resistance and the primary winding. Connect the appropriate load resistance and CH2 differential input across the secondary.

When using the transformer analyser fixture, the connections for insertion loss are made automatically by relays.

As the values of the load resistance, RI, and the source resistance, Rs, are used in the computation, it is important that both values are entered via the MODE menu.

16.9 <u>Harmonics and distortion</u>

Harmonic distortion introduced by a signal transformer may be measured either at a single spot harmonic or as the thd computed from a series of harmonics.

The primary of the transformer is energised either by the output of NumetriQ or by external means and CH2 is connected across the secondary. It is usual to measure harmonic distortion with the secondary loaded.

Specify the single harmonic, or the maximum series harmonic via the SETUP menu.

NumetriQ analyses for up to 50 harmonics in real time, using multiple DFTs (refer to the chapter on gain/phase analysis for the formulae for DFT analysis). Each harmonic is individually phase referenced to the fundamental so that the in-phase and quadrature components can be separately filtered. As the harmonics are usually very small, this technique is important to give adequate noise rejection.

The series harmonic data is combined to give the thd (refer to the chapter on harmonic analysis for the thd formula).

The single harmonic and the thd are expressed as dB relative to the fundamental.

16.10 Longitudinal balance

Longitudinal balance is a measure of the common mode rejection ratio, CMRR, of the transformer.

Longitudinal balance requires external circuitry to give the required accuracy – a plug in module is available for the transformer analyser fixture, TAF01, with precision resistors and active buffers adjacent to the transformer pins to minimise stray effects.

As a figure of merit, a higher value of longitudinal balance indicates a better transformer.

PSM3750 user manual

Transformer analyser specification

Transformer analyser	
frequency	10uHz to 35MHz (own generator)
	20mHz to 500kHz (external source)
measurement type	DFT analysis, true rms as appropriate
measurements	turns ratio
	turns
	inductance
	leakage inductance
	ac resistance
	dc resistance
	interwinding capacitance
	insertion loss
	return loss
	harmonics
	thd
	longitudinal balance
conditions	auto, or manual
display	numeric values
	table of sweep results
	graph of any measurement
accuracy	refer to other functions
sweep capability	all ac functions
sweep step rate	1/20s, 1/3s or 2.5s (approx.)
Appendix A – Accessories

<u>ACCESSORIES</u>

Power meter adaptors

The power meter adaptors allow easy and safe connection of the NumetriQ to a mains appliance under test to measure the power or harmonics.

The appliance under test plugs into an IEC mains outlet on the adaptor, which contains an isolating voltage transformer and current transformer with precision low resistance shunt.

The adaptor is fitted with an IEC mains inlet for use with an appropriate mains lead.

When the adaptor is plugged into the mains and the mains switched on, the appliance is energised and NumetriQ can be used to measure the power or harmonics.

Leave the NumetriQ generator off (OUT menu) so that it will synchronise to the mains frequency.

Part numbers

500-058 IEC 10A power meter adaptor

<u>75Ω / 600Ω output adapter</u>

The generator output from the NumetriQ has a series impedance of 50Ω . The output adapter fits directly onto the front of the instrument and provides 2 outputs:

 75Ω via a BNC connector

 600Ω via 4mm sockets.

There are two versions of the adapter that have different spacing between the 4mm sockets:

 $\frac{1}{2}$ " (12.5mm) as commonly used for communications.

³/₄" (19mm) as standard on instruments.

In both cases, the red connector carries the output signal, the green or black connector is OV (connected to earth via the NumetriQ chassis).

The impedance conversion is resistive and does not limit the frequencies available from the generator (dc coupled). When driving into the characteristic impedance (75Ω or 600Ω as appropriate) the voltage delivered to the load will be half that delivered into open circuit.

Matching the source to the load impedance minimises reflections at higher frequencies and improves transient response, especially when driving long lengths of cable or transformers.

Part numbers

500-005	75/600 Ω adaptor with $\frac{1}{2}$ " spacing
500-026	75/600 Ω adaptor with ³ / ₄ " spacing

CommVIEW PC software

CommVIEW is a self contained software program for a PC, which facilitates communication with NumetriQ over RS232.

CommVIEW allows strings to be sent and received between a PC and NumetriQ. The strings can be viewed in a window and optionally stored in a file. Data received from NumetriQ may be displayed in normal scientific notation with an identifying label.

Strings to be sent to NumetriQ can be stored in a "script file" and executed automatically. The script file is created with any text editor and includes three types of lines (interpreted by the first character on each line):

lines beginning with " are sent to NumetriQ lines beginning with # are commands for CommVIEW any other line is a comment.

The *#* commands that are recognised:

#beep	sound the beeper on the PC
#label,i,string	apply a label to data value[i]
#pause,t	wait for time t
#reply,t	wait time t for a reply

For an example script file, look at example.scr on the CommVIEW release disc.

Other functions in CommVIEW: save results results results menu set COM port parameters configure menu firmware upgrade instrument menu read/store user programs instrument menu

Appendix B – Serial command summary

command format	reply format
*CLS *ESE,value *ESE? *ESR? *IDN? *OPC?	single integer data value single integer data value company,product,serial no,version 0 or 1
*RST *SRE,value	single integer data value
*SRE? *STB? *TRG	single integer data value
*TST? *WAI	single integer data value
ABORT ACTRIM,channel,level,tol ALARM latch sounder	
ALARM?	single integer data value
ALARME, ALARME? ALARM1,type,data,high,low ALARM2,type,data,high,low AMPLIT,amplitude BANDWI,type BEEP BLANKI,on/off,threshold	single integer data value
CONFIG, parameter, data CONFIG, parameter?	single integer or real data value
COUPLI, channel? DATALO. function. interval	single integer data value
DATALO, start, records? DAV? DAVER, value	index,time,data one record per line single integer data value
DAVER? FILTER, type, dynamics	single integer data value
FRA? FRA,SWEEP? FREQUE,frequency FSWEEP,steps,start,end	freq,mag1,mag2,dB,phase n lines of GAINPH? data

GAINPH	
GAINPH?	freq,mag1,mag2,dB,phase
GAINPH, SWEEP?	n lines of GAINPH? data
HARMON,scan,para,h,hmax	
HARMON? or	freq,mag1,mag2,hmag1,hmag2,h1,h2 freq,mag1,mag2,thd1,thd2,h1,h2
HARMON, SWEEP?	n lines of HARMON? data
HARMON, SERIES?	mag1,%1,\1,mag2,%2,\2
	1 line for each harmonic
HOLD,on/off	
INPUT,channel,type	
INTYPE, channel, type	
INPUT, channel?	single integer data value
KEYBOA, value	
LCR,conditions,param,head	
LCR?	freq, mag1, mag2, impedance, phase,
	R, L, C (series), R, L, C (parallel),
	tanδ, Q, reactance
or	freq, mag1, mag2, impedance, phase,
	resistance, reactance, admittance,
	phase, conductance, susceptance
LCR, SWEEP?	n lines of data:
	freq,QF,tan&,impedance,phase,L,C,R
or	freq,QF,tan&,admittance,phase,L,C,R
LOWFRE, on/off	
MODE,type	
OFFSET,offset	
OUTPUT,type,sweep	
PAV,parameter,scaling	
PAV?	freq,mag1,mag2,parameter,phase,a,b
PAV, SWEEP?	n lines of VECTOR? data
PHASE	- · ·
PHASE?	freq,phase
PHASE, STREAM, window	phase,phase,phase,phase,phase,
PHCONV, convention	
PHREF, channel	
POWER, integration type	
POWER, WAITS?	W,W.t,VA,VA.t,pt,pt.t,Wdc,W.h,freq
POWER, RMS?	$rms1,rms2,dc1,dc2,fnd1,fnd2,\phi1,\phi2$
POWER, INTEGR?	wn,wn.t,wan,van.t,pt,pt.t,an,an.t,t
PPORT, Value	
PPOC DAM functions must be	single integer data value
PROGRAW, FUNCTION, NUMBER	CD terminated taxt string
PKUGKAW?	CK terminated text string

PSM3750 user manual

RANGE,ch,ranging,range RESOLU.format REZERO SCALE.channel.factor	
SCALE, channel? SHUNT, channel, resistance	single real data value
SHUNT, channel? SINGLE, on/off SPEED, speed[, window] SSWEEP, function, number START	single real data value
STATUS,channel? STOP	range number,range text,over/low/ok
STREAM,enable,window STREAM,disable	
STREAM? SUSPEND,on/off TFA	data, data, data, data, data,
TFA?	freg.mag1.mag2.dB.phase
TFA SWEEP?	n lines of GAINPH? data
TXA test fixture load source	
ΤΧΑ, το στ, πλται ο, ποαα, σο αι σο	free mad1 mad2 narameter
	n lines of TXA2 data
TXTEST tost wind1 wind2	
HSED2	3 CP terminated text strings
VECTOR parameter scaling	5 er terminated text strings
VECTOR?	free mad mad narameter phase a h
VECTOR SWEEP?	n lines of VECTOR2 data
VERSION2	datecode cou den finda boot
VRMS	datecode,cpd,dsp,ipgd,boot
VRMS?	RMS? data followed by SURGE?
VRMS.RMS?	rms1.rms2.dc1.dc2.ac1.ac2.db1.db2
VRMS, SURGE?	pk1,pk2,cf1,cf2,surge1,surge2
WAVEFO, type	
ZERO	
ZERO, DELETE	
ZOOM, level, d1, d2, d3, d4	
ZOOM?	level,d1,d2,d3,d4

calibration commands

CALAPP	
CALCOM, IT eq	
CALFIL?	six real data values
CALFRQ, index, freq	
CALFRQ?	seven real data values
CALIBR, index, value	
CALIBR?	single integer data value
CALOUT, index, value	
CALPHA, index	
CALRES	
CALSAV, password	
CALSNO, serial number	
CALSTR, string	
CALSTR?	string

Appendix C – Available character set

The following characters can be selected in text entry mode.

The table is to be read across then down (eg, starting at space and repeatedly pressing NEXT gives ! " # \$ % & ' () * etc.)

	ļ	11	#	\$	%	&	1
()	*	+	ı	-		/
0	1	2	3	4	5	6	7
8	9	:	• ,	<	=	>	?
@	А	В	С	D	Е	F	G
Н	I	J	К	L	М	Ν	0
Ρ	Q	R	S	Т	U	V	W
Х	Υ	Ζ	[١]	Λ	_
I	а	b	С	d	е	f	g
h	i	j	k	Ι	m	n	0
р	q	r	S	t	u	V	W
х	У	Z	{		}		

Appendix D – Configurable parameters

All parameters can be accessed using the CONFIG command:

CONFIG, parameter? CONFIG, parameter, data

Number Function

System parameters

1	operating mode
3	bandwidth auto or wide
4	autozero manual or auto
5	blanking disable
6	phase convention
7	main output on/off
8	line drawing on/off
9	keyboard beep on/off
11	low frequency mode
12	user window size
13	measurement speed
14	filter type
15	filter dynamics
16	baud rate
17	program step enable
18	sweep steps
19	sweep start frequency
20	sweep stop frequency
21	single sweep / continuous sweep
22	auto conditions
23	auto shunt
	Input parameters
24	enable channel 1
25	enable channel 2
26	input range channel 1
27	input range channel 2
28	input ranging channel 1
29	input ranging channel 2

- 30 coupling channel 1
- 31 coupling channel 2
- 32 scale factor channel 1
- 33 scale factor channel 2
- 34 external shunt channel 1
- 35 external shunt channel 2
- 36 input connection channel 1
- 37 input connection channel 2

General parameters

- 38 5/6 digit resolution
- 39 phase reference
- 40 output scaling
- 41 output resolution

Display parameters

- 42 zoom level
- 43 function zoomed on 1
- 44 function zoomed on 2
- 45 function zoomed on 3
- 46 function zoomed on 4
- 47 display type

Signal generator parameters

- 48 generator frequency
- 49 generator amplitude
- 50 generator offset
- 51 generator waveform
- 52 delta frequency
- 53 delta amplitude
- 54 generator amplitude in dBm
- 55 generator action at end of sweep

Datalog parameters

- 58 datalog memory type
- 59 datalog interval

General parameters

- 66 program jump enable
- 67 PLC interface enable

Power meter parameters

83 integration type

Streaming parameters

- 95 data streaming
- 96 data streaming window size

Harmonic analyser parameters

- 99 mode
- 100 selected harmonic
- 101 maximum harmonic
- 102 computation

LCR sweep zero parameters

- 106 sweep compensation
- 107 compensation start frequency
- 108 compensation stop frequency
- 109 compensation steps

System parameters

- 116 dBm level control
- 117 step message enable
- 118 display sequence
- 119 length units

Transformer analyser parameters

- 121 test
- 122 fixture
- 123 winding 1
- 124 winding 2
- 125 source impedance
- 126 load impedance
- 127 nominal number of turns

TAF control parameters

- 130 source winding
- 131 load
- 132 measure 1
- 133 measure 2

LCR meter parameters

- 137 computation
- 138 series/parallel sweep
- 139 graph option
- 140 active head control
- 141 impedance lin/log
- 142 phase adjust value
- 143 reference impedance
- 144 reference type

gain/phase analyser parameters

- 147 phase or delay time selection
- dB offset
- 149 gain/phase margin enable
- 150 ratio selection

System parameters

- 151 minimum number of cycles
- 152 delay time
- 153 IEEE address
- 154 LAN enable

Alarm functions

- 156 alarm data
- 157 type
- 158 high threshold
- 159 low threshold
- 160 latching type
- 161 sounder enable

Analogue output parameters

- 164 analogue zero
- 165 analogue scale

Alarm functions

- 167 alarm 2 data
- 168 alarm 2 type
- 169 alarm 2 high threshold
- 170 alarm 2 low threshold

Graph functions

- 173 graph 2 manual/auto
- 174 graph 2 maximum
- 175 graph 2 minimum

Phase angle voltmeter parameters

- 177 computation
- 178 LVDT scaling
- 179 manual null meter ranging
- 180 null maximum
- 181 phase offset

Trim parameters

- 186 ac trim enable
- 188 ac trim level
- 190 trim tolerance

Other parameters

- 192 log/linear sweep
- 193 graph scaling manual/auto
- 194 manual graph scaling maximum
- 195 manual graph scaling minimum

Appendix E – Contact details

Please direct all queries or comments regarding the NumetriQ instrument or manual to:

Newtons4th Ltd. 30 Loughborough Rd. Mountsorrel LOUGHBOROUGH LE12 7AT United Kingdom

Tel: (0116) 230 1066international +44 116 230 1066Fax: (0116) 230 1061international +44 116 230 1061E-mail address:sales@newtons4th.comoffice@newtons4th.comWeb site:www.newtons4th.com

At Newtons4th Ltd. we have a policy of continuous product improvement and are always keen to hear comments, whether favourable or unfavourable, from users of our products.

An example comment form can be found at the end of this manual – if you have any comments or observations on the product please fill a copy of this form with as much detail as possible then fax or post it to us.

Alternatively send an e-mail with your comments.

PSM1735 NUMETRIQ comments				
serial number:	main release: dsp release: fpga release: boot release: (press SYS then LE	EFT)	te:	
your contact de	etails:			
comments:				
detailed descrip	otion of application	or circumstar	nces:	
Plea	se post or fax to Ne	wtons4th Lto		